

FALCOM A2D

(Including A2D-A/B/C and A2D-1)

Contents

| | | |
|----------|-------------------------------------------------------|-----------|
| 0 | INTRODUCTION..... | 5 |
| 0.1 | USED ABBREVIATIONS | 5 |
| 0.2 | RELATED DOCUMENTS | 5 |
| 0.3 | SECURITY..... | 6 |
| 0.4 | SAFETY STANDARDS | 8 |
| 1 | GSM 07.05 AND 07.07 COMMANDS..... | 10 |
| 1.1 | PREFACE | 10 |
| 1.2 | COMMANDS CONCERNING MODEM AND SIM CARD HARDWARE | 10 |
| 1.2.1 | AT+CGMI..... | 10 |
| 1.2.2 | AT+CGMM | 10 |
| 1.2.3 | AT+CGMR | 10 |
| 1.2.4 | AT+CGSN | 11 |
| 1.2.5 | AT+CIMI | 11 |
| 1.2.6 | AT+CCID | 11 |
| 1.3 | NETWORK REGISTRATION COMMANDS..... | 11 |
| 1.3.1 | AT+CPIN | 11 |
| 1.3.2 | AT+CREG | 12 |
| 1.3.3 | AT+COPS | 13 |
| 1.3.4 | AT+CSQ | 14 |
| 1.3.5 | AT+CCED | 15 |
| 1.4 | SERIAL LINK CONTROL COMMANDS | 16 |
| 1.4.1 | ATE..... | 16 |
| 1.4.2 | ATQ | 16 |
| 1.4.3 | ATV | 17 |
| 1.4.4 | AT&C | 17 |
| 1.4.5 | AT&D | 17 |
| 1.4.6 | AT&S..... | 18 |
| 1.4.7 | AT+IPR..... | 18 |
| 1.4.8 | AT+ICF..... | 19 |
| 1.4.9 | AT+IFC..... | 19 |
| 1.5 | CALL CONTROL COMMANDS | 20 |
| 1.5.1 | AT+CICB..... | 20 |
| 1.5.2 | ATD; | 20 |
| 1.5.3 | AT+SPEAKER | 21 |
| 1.5.4 | AT+VGR..... | 21 |
| 1.5.5 | AT+VGT..... | 21 |
| 1.5.6 | AT+VTS | 22 |
| 1.5.7 | AT+VTD..... | 22 |
| 1.5.8 | AT+SIDET..... | 22 |
| 1.5.9 | AT+ECHO | 23 |
| 1.5.10 | ATD | 25 |
| 1.5.11 | ATDL | 25 |
| 1.5.12 | ATA | 26 |
| 1.5.13 | ATS0 | 26 |
| 1.5.14 | ATH | 26 |
| 1.5.15 | +++..... | 26 |
| 1.5.16 | ATO | 27 |
| 1.5.17 | AT+CBST | 27 |
| 1.5.18 | AT%C | 28 |
| 1.5.19 | AT+DS | 28 |
| 1.5.20 | AT\N | 29 |
| 1.5.21 | Remote disconnection | 29 |
| 1.6 | CALL INFORMATION COMMANDS | 30 |
| 1.6.1 | AT+CR..... | 30 |
| 1.6.2 | AT+CRC | 30 |
| 1.6.3 | AT+ILRR | 31 |
| 1.6.4 | AT+DR | 31 |
| 1.7 | CALL SETTING COMMANDS | 32 |

| | | |
|---------|---------------------------------------|----|
| 1.7.1 | AT+CCFC | 32 |
| 1.7.2 | AT+CCWA | 33 |
| 1.7.3 | AT+CLIP | 33 |
| 1.7.4 | AT+CLIR | 34 |
| 1.7.5 | AT+COLP | 35 |
| 1.8 | PHONEBOOK COMMANDS | 36 |
| 1.8.1 | AT+CPBS | 36 |
| 1.8.2 | AT+CPBR | 36 |
| 1.8.3 | AT+CPBF | 37 |
| 1.8.4 | AT+CPBW | 38 |
| 1.9 | MESSAGE HANDLING COMMANDS | 39 |
| 1.9.1 | AT+CSCA | 39 |
| 1.9.2 | AT+CMGL | 39 |
| 1.9.3 | AT+CMGR | 41 |
| 1.9.4 | AT+CMGS | 43 |
| 1.9.5 | AT+CMSS | 44 |
| 1.9.6 | AT+CMGW | 44 |
| 1.9.7 | AT+CMGD | 46 |
| 1.10 | MESSAGE SETTING COMMANDS | 46 |
| 1.10.1 | AT+CSMS | 46 |
| 1.10.2 | AT+CPMS | 47 |
| 1.10.3 | AT+CMGF | 48 |
| 1.10.4 | AT+CSMP | 48 |
| 1.10.5 | AT+CSDH | 49 |
| 1.10.6 | AT+CSCS | 49 |
| 1.10.7 | AT+CNMI | 50 |
| 1.10.8 | AT+CSCB | 53 |
| 1.11 | FAX CLASS 1 COMMANDS | 54 |
| 1.11.1 | AT+FCLASS | 54 |
| 1.11.2 | AT+FTM | 54 |
| 1.11.3 | AT+FRM | 55 |
| 1.11.4 | AT+FTH | 55 |
| 1.11.5 | AT+FRH | 55 |
| 1.11.6 | AT+FTS | 56 |
| 1.11.7 | AT+FRS | 56 |
| 1.12 | FAX CLASS 2 COMMANDS | 56 |
| 1.12.1 | AT+FDT | 56 |
| 1.12.2 | AT+FDR | 57 |
| 1.12.3 | AT+FET | 57 |
| 1.12.4 | AT+FPTS | 57 |
| 1.12.5 | AT+FK | 58 |
| 1.12.6 | AT+FBOR | 58 |
| 1.12.7 | AT+FBUF | 58 |
| 1.12.8 | AT+FCQ | 59 |
| 1.12.9 | AT+FCR | 59 |
| 1.12.10 | AT+FDIS | 59 |
| 1.12.11 | AT+FDCC | 61 |
| 1.12.12 | AT+FLID | 61 |
| 1.12.13 | AT+FPHCTO | 61 |
| 1.12.14 | Fax Class 2 indication messages | 62 |
| 1.13 | FUNCTIONALITY COMMANDS | 63 |
| 1.13.1 | A/ | 63 |
| 1.13.2 | AT+GCAP | 63 |
| 1.13.3 | AT+CLK | 63 |
| 1.13.4 | AT+CPWD | 64 |
| 1.13.5 | AT+CFUN | 65 |
| 1.13.6 | AT+CPAS | 65 |
| 1.13.7 | AT+CPOF | 66 |
| 1.14 | STORING/RESTORING COMMANDS | 66 |
| 1.14.1 | AT&W | 66 |
| 1.14.2 | AT&F | 66 |

| | |
|--------------------------------------------------------------------------|-----------|
| 1.14.3 AT+CSAS | 67 |
| 1.14.4 AT+CRES | 67 |
| 1.14.5 What is stored where? What are the defaults? | 67 |
| 1.15 ERROR MESSAGE HANDLING AND SURVEY | 68 |
| 1.15.1 AT +CMEE | 68 |
| 1.15.2 Mobile equipment error result code : +CME ERROR: <err> | 69 |
| 1.15.3 Message service failure result code: +CMS ERROR: <err> | 69 |
| 1.15.4 Specific error result codes +CMS ERROR or +CME ERROR: <err> | 72 |
| 1.15.5 AT +CEER | 72 |
| 2 A2D-A / A2D-B | 74 |
| 2.1 TECHNICAL DATA | 74 |
| 2.2 POSSIBLE EXTERNAL DEVICES: | 75 |
| 2.3 CONNECTORS AT THE A2D | 76 |
| 2.4 PIN-OUT OF THE A2D MODULE | 77 |
| 2.5 SPECIAL FUNCTIONALITY PINS | 79 |
| 2.5.1 Pin 12 on C1 (EN) | 79 |
| 2.5.2 Pin 13 on C1 (GPIO 1 → Flash_LED) | 80 |
| 2.5.3 Pin 19 on C1 (SIMPRES) | 80 |
| 2.5.4 Pin 25 on C1 (3V SIM) | 81 |
| 2.5.5 Pin 26 on C1 (RSTF) | 81 |
| 2.5.6 Pin 29 on C1, Pin 3 on C2 (SOFT_ON) | 81 |
| 2.6 FIRMWARE DOWNLOAD PROCEDURE | 82 |
| 2.7 RESETTING THE A2D OEM MODULE VIA AT+CFUN=1,1 | 82 |
| 3 A2D-1 MODEM (FIRST VERSION) | 83 |
| 3.1 REMARKS | 83 |
| 3.2 TECHNICAL DATA | 83 |
| 3.3 CONNECTORS AT THE A2D-1 | 84 |
| 3.4 FUNCTIONAL DESCRIPTION | 85 |
| 3.4.1 Ignition line | 85 |
| 3.4.2 Serial handling | 86 |
| 3.4.3 Reset configuration | 86 |
| 3.4.4 Firmware update | 87 |
| 4 A2D-1 MODEM (SECOND VERSION) | 88 |
| 4.1 REMARKS | 88 |
| 4.2 TECHNICAL DATA | 88 |
| 4.3 CONNECTORS AT THE A2D-1 | 89 |
| 4.4 FUNCTIONAL DESCRIPTION | 90 |
| 4.4.1 Ignition line | 90 |
| 4.4.2 Serial handling | 91 |
| 4.4.3 Reset configuration | 91 |
| 4.4.4 SIM ACC LED | 92 |
| 4.4.5 Firmware update | 92 |
| 5 APPENDIX | 93 |
| 5.1 RECOMMENDATIONS FOR POWER SUPPLY LAYOUT (A2D-A/B/C) | 93 |
| 5.2 RECOMMENDATIONS FOR POWER SUPPLY (A2D-1) | 93 |
| 5.3 SIM-CARD READER FROM AMP | 93 |
| 5.4 DEVICE HOLDER FOR A2D-1 | 94 |
| 5.5 MOUNTING CLAMPS FOR A2D-A/B/C | 94 |

Version history:

| Version number | Author | Changes |
|----------------|-----------|---------------------------------------------------------------------------------------------------------------------|
| 1.00 | A. Ulrich | Initial version |
| 1.01 | A. Ulrich | Serial link controls, Modem default settings |
| 1.02 | A. Ulrich | Additional ERROR codes specified |
| 1.03 | A. Ulrich | AT+CPOF, AT+CIMI, AT+CCID, ATDL, A/ added; AT+CREG changed |
| 1.04 | A. Ulrich | Outfit changed |
| 1.05 | A. Ulrich | AT+CGMI, AT+CGMM changed, Document references changed |
| 1.06 | A. Ulrich | AT+CNMI changed; AT+SPEAKER, AT+CCED, AT+CICB, AT+ECHO, AT+SIDET, AT%C, AT+DS, AT+DR, AT\N added |
| 1.07 | A. Ulrich | Special functionality pins added; Fax commands added; A2D-1 section renewed |
| 1.08 | A. Ulrich | Factory default settings added, SIMPRES explanation added, A2D pin description changed |
| 1.09 | A. Ulrich | A2-1 section renewed, Power consumption changed, Graphics for A2D OEM module (C1!) updated, AT+CFUN remarks changed |
| 1.10 | A. Ulrich | Description of new A2D-1 added, AT+CGMI changed, 3V_SIM signal checked |

0 Introduction

This manual is focussed on the GSM data solutions of the FALCOM A2D series from FALCOM GmbH. It contains information about the FALCOM A2D embedded GSM module and the FALCOM A2D-1 GSM modem and phone. It does not contain special information about the GSM related accessories, as there are the dial-handset, the hands free set, the external battery pack and the mobile data terminals, which are also sold by FALCOM.

Information furnished herein by FALCOM GmbH is believed to be accurate and reliable. However, no responsibility is assumed for its use. Also the information contained herein is subject to change without notice.

Users are advised to quickly proceed to the “Security” chapter and read the hints carefully.

0.1 Used abbreviations

| | |
|--------|-------------------------------------------------|
| ETSI | European Telecommunications Standards Institute |
| GSM | Global System for Mobile communications |
| IMEI | International Mobile station Equipment Identity |
| ME | Mobile Equipment |
| PLMN | Public Land Mobile Network |
| PIN | Personal Identification Number |
| PUK | Personal Unblocking Key |
| RP | Receive Protocol |
| RXQUAL | Received Signal Quality |
| SIM | Subscriber Identity Module |
| SMS | Short Message Service |
| SMS/PP | Short Message Service/Point-to-Point |
| TA | Terminal Adapter |
| TE | Terminal Equipment |
| TP | Transmit Protocol |

0.2 Related documents

- ETSI GSM 07.05 “Use of Data Terminal Equipment - Data Circuit terminating Equipment interface for Short Message Service and Cell Broadcast Service“
- ETSI GSM 07.07 “AT command set for GSM Mobile Equipment”
- ITU-T V.25ter “Serial asynchronous automatic dialling and control”

0.3 Security

IMPORTANT FOR THE EFFICIENT AND SAFE OPERATION OF YOUR GSM MODEM READ THIS INFORMATION BEFORE USE !

Your GSM modem is one of the most exciting and innovative electronic products ever developed. With it you can stay in contact with your office, your home, emergency services, and others, wherever service is provided.

GENERAL

Your modem utilises the GSM standard for cellular technology. GSM is a newer radio frequency (« RF ») technology than the current FM technology that has been used for radio communications for decades. The GSM standard has been established for use in the European community and elsewhere.

Your modem is actually a low power radio transmitter and receiver. It sends out and receives radio frequency energy. When you use your modem, the cellular system handling your calls controls both the radio frequency and the power level of your cellular modem.

EXPOSURE TO RF ENERGY

There has been some public concern about possible health effects of using GSM modem. Although research on health effects from RF energy has focused for many years on the current RF technology, scientists have begun research regarding newer radio technologies, such as GSM. After existing research had been reviewed, and after compliance to all applicable safety standards had been tested, it has been concluded that the product is fit for use.

If you are concerned about exposure to RF energy there are things you can do to minimise exposure. Obviously, limiting the duration of your calls will reduce your exposure to RF energy. In addition, you can reduce RF exposure by operating your cellular modem efficiently by following the below guidelines.

EFFICIENT MODEM OPERATION

For your modem to operate at the lowest power level, consistent with satisfactory call quality :

If your modem has an extendible antenna, extend it fully. Some models allow you to place a call with the antenna retracted. However your modem operates more efficiently with the antenna fully extended.

Do not hold the antenna when the modem is « IN USE ». Holding the antenna affects call quality and may cause the modem to operate at a higher power level than needed.

ANTENNA CARE AND REPLACEMENT

Do not use the modem with a damaged antenna. If a damaged antenna comes into contact with the skin, a minor burn may result. Replace a damaged antenna immediately. Consult your manual to see if you may change the antenna yourself. If so, use only a manufacturer-approved antenna. Otherwise, have your antenna repaired by a qualified technician. Use only the supplied or approved antenna. Unauthorised antennas, modifications or attachments could damage the modem and may contravene local RF emission regulations or invalidate type approval.

DRIVING

Check the laws and regulations on the use of cellular devices in the area where you drive. Always obey them. Also, when using your modem while driving, please : give full attention to driving, pull off the road and park before making or answering a call if driving conditions so require. When applications are prepared for mobile use they should fulfil road-safety instructions of the current law!

ELECTRONIC DEVICES

Most electronic equipment, for example in hospitals and motor vehicles is shielded from RF energy. However RF energy may affect some malfunctioning or improperly shielded electronic equipment.

VEHICLE ELECTRONIC EQUIPMENT

Check your vehicle manufacturer's representative to determine if any on board electronic equipment is adequately shielded from RF energy.

MEDICAL ELECTRONIC EQUIPMENT

Consult the manufacturer of any personal medical devices (such as pacemakers, hearing aids, etc...) to determine if they are adequately shielded from external RF energy.

Turn your modem **OFF** in health care facilities when any regulations posted in the area instruct you to do so. Hospitals or health care facilities may be using RF monitoring equipment.

AIRCRAFT

Turn your modem **OFF** before boarding any aircraft.

Use it on the ground only with crew permission.

Do not use in the air.

To prevent possible interference with aircraft systems, Federal Aviation Administration (FAA) regulations require you to have permission from a crew member to use your modem while the plane is on the ground. To prevent interference with cellular systems, local RF regulations prohibit using your modem whilst airborne.

CHILDREN

Do not allow children to play with your modem. It is not a toy. Children could hurt themselves or others (by poking themselves or others in the eye with the antenna, for example). Children could damage the modem, or make calls that increase your modem bills.

BLASTING AREAS

To avoid interfering with blasting operations, turn your unit **OFF** when in a « blasting area » or in areas posted : « turn off two-way radio ». Construction crew often use remote control RF devices to set off explosives.

POTENTIALLY EXPLOSIVE ATMOSPHERES

Turn your modem **OFF** when in any area with a potentially explosive atmosphere. It is rare, but your modem or its accessories could generate sparks. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Areas with a potentially explosive atmosphere are often, but not always, clearly marked. They include fuelling areas such as petrol stations ; below decks on boats ; fuel or chemical transfer or storage facilities ; and areas where the air contains chemicals or particles, such as grain, dust, or metal powders.

Do not transport or store flammable gas, liquid, or explosives, in the compartment of your vehicle which contains your modem or accessories. Before using your modem in a vehicle powered by liquefied petroleum gas (such as propane or butane) ensure that the vehicle complies with the relevant fire and safety regulations of the country in which the vehicle is to be used.

NON-IONISING RADIATION

As with other mobile radio transmitting equipment , users are advised that for satisfactory operation and for the safety of personnel, it is recommended that no part of the human body be allowed to come too close to the antenna during operation of the equipment.

The radio equipment shall be connected to the antenna via a non-radiating 50Ohm coaxial cable.

The antenna shall be mounted in such a position that no part of the human body will normally rest close to any part of the antenna. It is also recommended to use the equipment not close to medical devices as for example hearing aids and pacemakers.

0.4 Safety standards

THIS CELLULAR MODEM COMPLIES WITH ALL APPLICABLE RF SAFETY STANDARDS.

This cellular modem meets the standards and recommendations for the protection of public exposure to RF electromagnetic energy established by governmental bodies and other qualified organisations, such as the following :

- Directives of the European Community, Directorate General V in Matters of Radio Frequency Electromagnetic Energy.

1 GSM 07.05 and 07.07 commands

1.1 Preface

In the following the <err> parameter is sometimes shown. This parameter and its possible values are described in chapter “ Error message handling and survey”.

1.2 Commands concerning modem and SIM card hardware

1.2.1 AT+CGMI

Command gives manufacturer information.

| Command | Possible responses |
|---------|--------------------|
| +CGMI | Falcom_A2D_V1.01 |
| +CGMI=? | OK |

Remarks: none

Source: GSM 07.07/5.1

Implementation: complete

1.2.2 AT+CGMM

Command gives GSM model information.

| Command | Possible responses |
|---------|---------------------|
| +CGMM | MULTIBAND 900E 1800 |
| +CGMM=? | OK |

Remarks: none

Source: GSM 07.07/5.2

Implementation: complete

1.2.3 AT+CGMR

Command gives firmware revision information.

| Command | Possible responses |
|---------|--------------------|
| +CGMR | <version number> |
| +CGMR=? | OK |

Remarks: none

Source: GSM 07.07/5.3

Implementation: complete

1.2.4 AT+CGSN

Command gives IMEI information.

| Command | Possible responses |
|----------------|---------------------------|
| +CGSN | <IMEI> |
| +CGSN=? | OK |

Remarks: none
Source: GSM 07.07/5.4
Implementation: complete

1.2.5 AT+CIMI

Command gives IMSI information.

| Command | Possible responses |
|----------------|---------------------------|
| +CIMI | <IMSI> |
| +CIMI=? | OK |

Remarks: none
Source: GSM 07.07/5.6
Implementation: complete

1.2.6 AT+CCID

Command gives EF-CCID file information.

| Command | Possible responses |
|----------------|---------------------------|
| +CCID | +CCID: <id> |
| +CCID=? | OK |

Defined values

<id>: EF-CCID file in hexadecimal format

Remarks: none
Source: factory default
Implementation: complete

1.3 Network registration commands

1.3.1 AT+CPIN

Command is used to send the PIN to the modem, which is needed to register into the GSM network.

After three unsuccessful attempts to enter the PIN the PUK is required. As second parameter the user should provide a new PIN. After 10 unsuccessful attempts to enter the PUK the SIM card is damaged.

| Command | Possible responses | |
|-----------------------|--------------------|-------------------|
| +CPIN=<pin> | OK | +CME ERROR: <err> |
| +CPIN=<puk>,<new pin> | OK | +CME ERROR: <err> |
| +CPIN? | +CPIN: <code> | +CME ERROR: <err> |
| +CPIN=? | OK | |

Defined values:

<pin>, <newpin>: 4 to 8 digits string type value

<puk>: 8 digits string type value

<code>: READY Modem is not pending for any password

SIM PIN Modem is waiting SIM PIN to be given

SIM PUK Modem is waiting SIM PUK to be given

Remarks: +CME ERROR: 16
shows up if wrong PIN is entered.

+CME ERROR: 12
shows up if wrong PUK number is entered.

+CME ERROR: 13
SIM card is damaged .

+CME ERROR: 10
means that no SIM card is inserted.

Source: GSM 07.07/8.3

Implementation: complete

1.3.2 AT+CREG

Command is used to show the network registration status and to control the presentation of an unsolicited result code +CREG: <stat> when there is a change in the network registration status.

| Command | Possible responses | |
|----------------------------------|------------------------------------|-------------------|
| +CREG=[<n>] | OK | |
| Unsolicited result codes: | | |
| | +CREG: <stat> | if <n> equals 1 |
| | +CREG: <stat>,<lac>,<ci> | if <n> equals 2 |
| +CREG? | +CREG: <n>,<stat> (n=1) | +CME ERROR: <err> |
| | +CREG: <n>,<stat>,<lac>,<ci> (n=2) | |
| +CREG=? | +CREG: (list of supported <n>s) | +CME ERROR: <err> |

Defined values:

| | | |
|------------------------|----------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------|
| <n>: | 0 | disable network registration unsolicited result code |
| | 1 | enable network registration unsolicited result code |
| | 2 | enable network registration unsolicited result code with <lac> and <ci> |
| <stat>: | 0 | not registered, ME is not currently searching a new operator to register to |
| | 1 | registered, home network |
| | 2 | not registered, but ME is currently searching a new operator to register to |
| | 3 | registration denied |
| | 4 | unknown |
| | 5 | registered, roaming |
| <lac>: | String type; two byte location area code in hexadecimal format (e.g. “00C3” equals 193 in decimal) | |
| <ci>: | String type; two byte cell ID in hexadecimal format | |
| Remarks: | none | |
| Source: | GSM 07.07/7.2 | |
| Implementation: | complete | |

1.3.3 AT+COPS

Command is used to show the current and the available PLMN's. It is also used to select a PLMN manually or automatically.

| Command | Possible responses | |
|------------------------------------|---------------------------------------------------------------------------------------------------------|-------------------|
| +COPS=[<mode>[,<format>[,<oper>]]] | OK | +CME ERROR: <err> |
| +COPS? | +COPS: <mode>[,<format>,<oper>] | +CME ERROR: <err> |
| +COPS=? | +COPS: list of supported(<stat>, <long alphanumeric oper>, <short alphanumeric oper>, <numeric oper>,)s | +CME ERROR: <err> |

Defined values:

| | | |
|------------------------|---|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <mode>: | 0 | automatic (<oper> field is ignored) |
| | 1 | manual (<oper> field shall be present) |
| <format>: | 2 | numeric <oper> |
| <oper>: | | string type; GSM Location Area Identification number which consists of a three BCD digit country code coded as in ITU-T E.212 annex A [10], plus a two BCD digit network code, which is administration specific |
| <stat>: | 0 | unknown |
| | 1 | available |
| | 2 | current |
| | 3 | forbidden |
| Remarks: | | none |
| Source: | | GSM 07.07/7.3 |
| Implementation: | | complete |

1.3.4 AT+CSQ

Command is used to ask for the networks field strength and the current bit error rate.

| Command | Possible responses | |
|---------|--------------------------------------------------------------|-------------------|
| +CSQ | +CSQ: <rssi>,<ber> | +CME ERROR: <err> |
| +CSQ=? | +CSQ: (list of supported <rssi>s),(list of supported <ber>s) | |

Defined values:

| | | |
|---------------------|--------|-----------------------------------------------------------------|
| <rssi>: | 0 | -113 dBm or less |
| | 1 | -111 dBm |
| | 2...30 | -109... -53 dBm |
| | 31 | -51 dBm or greater |
| | 99 | not known or not detectable |
| <ber> (in percent): | 0...7 | as RXQUAL values in the table in GSM 05.08 [20] subclause 8.2.4 |
| | 99 | not known or not detectable |

| | |
|------------------------|-------------------------------------------------------------------------------------------------------------------------|
| Remarks: | For a reliable online data connection the <rssi> value should be greater than 9. The <ber> value should never exceed 3. |
| Source: | GSM 07.07/8.5 |
| Implementation: | complete |

1.3.5 AT+CCED

This command can be used by the application to retrieve the cell parameters of the main cell and of up to six neighbour cells.

The response will be :

```
[+CSQ: <rssi>,99 if <requested dump> equals 8 to 15]
+CCED :<value>, ... , <value>
OK
```

where <value> is the ASCII string of the values (in decimal except LAC and CI values are in hexadecimal) of the parameters. If a field can not be measured - or has no sense - the parameter is not filled (two consecutive commas are then found). The meaning of <value> can be found in GSM ETSI 01.04.

The response could be a single shot or automatically sent to the serial link every 5sec.

| Command | Possible responses |
|------------------------------------|--------------------|
| AT+CCED=<mode>[, <requested dump>] | OK |

Defined values:

| | | |
|------------------|---|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <mode> | 0 | One shot requested |
| | 1 | Automatic shots requested |
| | 2 | Stop automatic shots |
| <requested dump> | 1 | Main Cell if the Cell Identity is available: MCC, MNC, LAC, CI, BSIC, BCCH Freq (absolute), RxLev, RxLev Full, RxLev Sub, RxQual, RxQual Full, RxQual Sub, Idle TS if the Cell Identity is not available: MCC, MNC, LAC,, BSIC, BCCH Freq (absolute), RxLev, RxLev Full, RxLev Sub, RxQual, RxQual Full, RxQual Sub, Idle TS |
| | 2 | Neighbour1 to Neighbour6 if the Cell Identity is available MCC, MNC, LAC, CI, BSIC, BCCH Freq (absolute), RxLev if the Cell Identity is not available MCC, MNC, LAC,, BSIC, BCCH Freq (absolute), RxLev |
| | 4 | Timing Advance |
| | 8 | Main cell RSSI indications (RxLev) from 0 to 31. |

Combination (addition of the values) of the requested dumped are supported.

| | |
|------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Remarks: | Notice that in idle mode, only RxLev measures (on the main cell and on the neighbour cells) are done. The value of these RxLev is set in the RxLev Full field for the main cell. Values of MCC/MNC are set to 0 in case of “No service”. For the request of RSSI the bit error rate is not measured. |
| Source: | factory default |
| Implementation: | complete |

1.4 Serial link control commands

1.4.1 ATE

The setting of this parameter determines whether or not the DCE echoes characters received from the DTE during command state and online command state.

| Command | Possible responses |
|------------|--------------------|
| E[<value>] | OK |

Defined values:

| | |
|----------|------------------------------------------------------------------------------------|
| <value>: | 0 DCE does not echo characters during command state and online command state. |
| | 1 DCE echoes characters during command state and online command state. |

| | |
|------------------------|---------------|
| Remarks: | none |
| Source: | V.25ter/6.2.4 |
| Implementation: | complete |

1.4.2 ATQ

The setting of this parameter determines whether or not the DCE transmits result codes to the DTE. When result codes are being suppressed, no portion of any intermediate, final, or unsolicited result code – header, result text, line terminator, or trailer – is transmitted. Information text transmitted in response to commands is not affected by the setting of this parameter.

| Command | Possible responses |
|------------|--------------------|
| Q[<value>] | OK |

Defined values:

| | |
|----------|---------------------------------------------------------|
| <value>: | 0 DCE transmits result codes. |
| | 1 Result codes are suppressed and not transmitted. |

| | |
|-----------------|---------------|
| Remarks: | none |
| Source: | V.25ter/6.2.5 |

Implementation: complete

1.4.3 ATV

The setting of this parameter determines the contents of the header and trailer transmitted with result codes and information responses. It also determines whether result codes are transmitted in a numeric form or an alphabetic (or "verbose") form. The text portion of information responses is not affected by this setting.

| Command | Possible responses |
|------------|--------------------|
| V[<value>] | OK |

Defined values:

- | | |
|----------|---------------------------------------------------------------------------|
| <value>: | 0 DCE transmits limited headers and trailers and numeric text. |
| | 1 DCE transmits full headers and trailers and verbose response text. |

Remarks: none

Source: V.25ter/6.2.6

Implementation: complete

1.4.4 AT&C

This parameter determines how the state of circuit 109 (DCD) relates to the detection of received line signal from the distant end.

| Command | Possible responses |
|-------------|--------------------|
| &C[<value>] | OK |

Defined values:

- | | |
|----------|----------------------------------------------------------------|
| <value>: | 0 DCD always on |
| | 1 DCD matches the state of the remote modems data carrier |

Remarks: none

Source: V.25ter/6.2.8

Implementation: complete

1.4.5 AT&D

This parameter determines how the DCE responds when circuit 108/2 (DTR) is changed from the ON to the OFF condition during online data state.

| Command | Possible responses |
|-------------|--------------------|
| &D[<value>] | OK |
| &D? | <value> |

Defined values:

| | |
|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| <value>: | 0 DTR is ignored. |
| | 1 Upon an on-to-off transition of DTR, the DCE enters online command state and issues an OK result code; the call remains connected. |
| | 2 Upon an on-to-off transition of DTR, the DCE instructs the underlying DCE to perform an orderly clear-down of the call. |
| Remarks: | none |
| Source: | V.25ter/6.2.9 |
| Implementation: | complete |

1.4.6 AT&S

This parameter controls the DSR (Data Set Ready) signal.

| Command | Possible responses |
|------------------------------|---------------------------|
| &S[<value>] | OK |

Defined values:

| | |
|-----------------------|----------------------------------------------------|
| <value>: | 0 DSR is always on. |
| | 1 DSR off in command mode, on in online mode. |

| | |
|------------------------|-----------------|
| Remarks: | none |
| Source: | factory default |
| Implementation: | complete |

1.4.7 AT+IPR

This numeric extended-format parameter specifies the data rate at which the DCE will accept commands.

| Command | Possible responses |
|--------------------------|----------------------------------------------------------------------------------------------------------|
| +IPR=<rate> | OK |
| +IPR? | +IPR:<rate> |
| +IPR=? | +IPR: [list of auto-bauding-capable <rate> values],[list of fixed-only <rate> values] |

Defined values:

| | |
|----------------------|---------------------------------------------------------------------------------------------------------------|
| <rate>: | Value specified shall be the rate in bits per second. A value of 0 switches into auto-bauding mode. |
|----------------------|---------------------------------------------------------------------------------------------------------------|

| | |
|-----------------|----------------------------------------------------------------------------------------------------------------|
| Remarks: | The auto-bauding mode needs to have the characters in capital letters, otherwise they could not be recognised. |
|-----------------|----------------------------------------------------------------------------------------------------------------|

Source: V.25ter/6.2.10
Implementation: complete

1.4.8 AT+ICF

This extended-format compound parameter is used to control the asynchronous character framing between the DTE and DCE.

| Command | Possible responses |
|----------------------------|----------------------------------------------------------------|
| +ICF=[<format>[,<parity>]] | OK |
| +ICF? | +ICF: [<format>[,<parity>]] |
| +ICF=? | +ICF: list of supported <format>s, list of supported <parity>s |

Defined values:

| | | |
|------------|---|------------------------|
| <format>: | 1 | 8 Data 2 Stop |
| | 2 | 8 Data 1 Parity 1 Stop |
| | 3 | 8 Data 1 Stop |
| | 4 | 7 Data 2 Stop |
| | 5 | 7 Data 1 Parity 1 Stop |
| | 6 | 7 Data 1 Stop |
| <parity> : | 0 | Odd |
| | 1 | Even |
| | 4 | None |

Remarks: none
Source: V.25ter/6.2.11
Implementation: complete

1.4.9 AT+IFC

This extended-format compound parameter is used to control the operation of local flow control between the DTE and DCE.

| Command | Possible responses |
|--------------------------|------------------------------------------------------|
| +IFC=<DCE_DTE>,<DTE_DCE> | OK |
| +IFC? | +IFC: <DCE_DTE>,<DTE_DCE> |
| +IFC=? | +IFC: list of supported <DCE_DTE>,<DTE_DCE> settings |

Defined values:

| | | |
|------------|---|----------|
| <DCE_DTE>: | 0 | None |
| | 2 | RTS line |
| <DTE_DCE>: | 0 | None |
| | 2 | CTS line |

Remarks: none
Source: V.25ter/6.2.12
Implementation: complete

1.5 Call control commands

1.5.1 AT+CICB

Command is used to set the bearer type if no bearer is transmitted on an incoming call.

| Command | Possible responses |
|-------------|-------------------------------|
| AT+CICB=<n> | OK |
| AT+CICB? | +CICB: <n> |
| AT+CICB=? | +CICB: list of supported <n>s |

Defined values:

<n> Simulated incoming bearer.

| | |
|---|-------|
| 0 | Data |
| 1 | Fax |
| 2 | Voice |

Remarks: If a wrong bearer is transmitted, the CICB setting has no effect.
Source: factory default
Implementation: complete

1.5.2 ATD:

Command is used to establish a voice call.

| Command | Possible responses |
|--------------|------------------------------------------------------|
| ATD<number>; | OK If call is established |
| | BUSY If called party is in another call |
| | NO ANSWER If called party does not accept a call |
| | NO CARRIER If there are problems to establish a call |

Defined values:

<number>: Telephone number to dial.

Remarks: In case of international number, the local international prefix (usually 00) could be replaced by the '+' character.
For phonebook dialling please see phonebook commands section.
Source: GSM 07.07/V.25ter/6.3.1
Implementation: complete

1.5.3 AT+SPEAKER

Command is used to switch between the internal speaker and microphone lines for the A2D-A/B/C series or to switch them on and off for the A2D-1.

| Command | Possible responses |
|----------------|------------------------------------|
| AT+SPEAKER=<n> | OK |
| AT+ SPEAKER? | + SPEAKER: <n> |
| AT+ SPEAKER =? | +SPEAKER: (list of supported <n>s) |

Defined values:

| | |
|-----|------------------------------------------------------------------------------------------------|
| <n> | 0 Speaker 1 and Microphone 1 are active. 1 Speaker 2 and Microphone 2 are active. |
|-----|------------------------------------------------------------------------------------------------|

Remarks: The A2D-1 series has got no Speaker 2 and Microphone 2 audio lines, so AT+SPEAKER=1 turns the Audio section off.

Source: factory default

Implementation: complete

1.5.4 AT+VGR

Command is used to set the attenuation of the modules loudspeaker.

| Command | Possible responses |
|------------|--------------------------|
| AT+VGR=<n> | OK |
| AT+VGR? | +VGR: <n> |
| AT+VGR=? | (list of supported <n>s) |

Defined values:

| | |
|-----|-----------------------------------------------------|
| <n> | Integer , range 0...255, where 128 is nominal gain. |
|-----|-----------------------------------------------------|

Remarks: none

Source: GSM 07.07/C.4

Implementation: complete

1.5.5 AT+VGT

Command is used to set the amplification of the modules microphone.

| Command | Possible responses |
|------------|--------------------------|
| AT+VGT=<n> | OK |
| AT+VGT? | +VGT: <n> |
| AT+VGT=? | (list of supported <n>s) |

Defined values:

| | |
|-----|-----------------------------------------------------|
| <n> | Integer , range 0...255, where 128 is nominal gain. |
|-----|-----------------------------------------------------|

Remarks: none
Source: GSM 07.07/C.5
Implementation: complete

1.5.6 AT+VTS

Command is used to transmit DTMF tones.

| Command | Possible responses |
|---------------|-----------------------------|
| AT+VTS=<tone> | OK |
| AT+VTS=? | (list of supported <tone>s) |

Defined values:

<tone> A single ASCII character in the set 0-9, #,* ,A-D.

Remarks: none.
Source: GSM 07.07/C.11
Implementation: complete

1.5.7 AT+VTD

Command is used to set the length of DTMF tones emitted.

| Command | Possible responses |
|------------|--------------------------|
| AT+VTD=<n> | OK |
| AT+VTD? | +VTD: <n> |
| AT+VTD=? | (list of supported <n>s) |

Defined values:

<n> Tone of duration <n>*100 milliseconds.

Remarks: If n < 4 the tone duration is 300 ms.
Source: GSM 07.07/C.12
Implementation: complete

1.5.8 AT+SIDET

Command is used to set the availability and attenuation of the microphone signal in the speaker.

| Command | Possible responses |
|--------------------|----------------------------------------------------|
| AT+ SIDET =<n>,<m> | OK |
| AT+ SIDET? | + SIDET: <n>,<m> |
| AT+ SIDET =? | (list of supported <n>s), (list of supported <m>s) |

Defined values:

| | | |
|-----|---|------------------------|
| <n> | 0 | Side tone is disabled. |
| | 1 | Side tone is enabled. |

| | | |
|-----|---|------------------|
| <m> | 0 | $\pm 0\text{dB}$ |
| | 1 | -6dB |
| | 2 | -12dB |
| | 3 | -18dB |

Remarks: none
Source: factory default
Implementation: complete

1.5.9 AT+ECHO

Command is used to enable and set the echo cancellation or the switch attenuation parameters for the audio lines.

| Command | Possible responses |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|
| AT+ECHO= <mode>, [<Taps>,<ConvTh>,<DbtS>, <FarS>,<EcDelay>] (for echo cancellation) [<Volout>,<Step>,<PcmThrel>, <PcmThmax>,<EcGain>] (for switch attenuation) | OK |
| AT+ECHO? | +ECHO: <Status>,<Taps>,<ConvTh>,<DbtS>, <FarS>,<EcDelay> +ECHO: <Status>,<Volout>,<Step>,<PcmThrel>, <PcmThmax>,<EcGain> |

Defined values:

| | | |
|--------|---|------------------------------------------------------------|
| <mode> | 0 | Deactivate Echo |
| | 1 | Activate Echo |
| | 2 | Configure echo cancellation (automatically stored in E2P) |
| | 3 | Deactivate switch attenuation |
| | 4 | Activate switch attenuation |
| | 5 | Configure switch attenuation (automatically stored in E2P) |

<Taps> This parameter specifies the number of taps of the adaptive filter used for echo cancellation. The allowed range is [2 ; 255].

<ConvTh> This parameter specifies the level of needed convergence. A low value provides a high convergence and a high value a high stability. The allowed range is [0 ; 4095].

<DbtTalk > A negative value provides a high sensitivity and a positive value a low one. The allowed range is [0 ; 10].

| | |
|-------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <FarS> | If Far-end speaker detection = 0, the algorithm will always adjust the filter. For other values, adaptation runs only if far end speaker energy is greater than Far end speaker detection value. The allowed range is [0 ;1000]. |
| <EcDelay> | Number of samples used to compute energy for algorithm convergence evaluation. The allowed range is [0 ;63]. |
| <Volout> | This parameter specifies the maximum attenuation of the switch. |
| | 0 31 db 1 29 db 2 27 db 3 25 db . . 14 3 db 15 1 db |
| <Step> | This parameter specifies the attenuation step between attenuation and no attenuation. |
| | 0 1 db 1 2 db 2 3 db 3 4 db |
| <PcmThRel> | This parameter specifies the relative threshold between max and min energy information. The allowed range is [0 ; 31]. |
| <PcmThMax > | This parameter specifies threshold of max energy information. The allowed range is [0 ; 31]. |
| <EcGain> | This parameter specifies the attenuation for switch when echo algorithm has converged. This parameter is used by echo algorithm when echo and switched are activated together. |
| | 0 14 db 1 12 db 2 10 db 3 8 db 4 6 db 5 4 db 6 2 db 7 1 db |

| | | |
|----------|---|------------------------------------|
| <Status> | 0 | Echo Deactivated. |
| | 1 | Echo Activated for Mic1/Speaker1 . |
| | 2 | Echo Activated for Mic2/Speaker 2. |

Remarks: For the A2D-1 there is no Microphone2 and Speaker2 available.

Source: factory default

Implementation: complete

1.5.10 ATD

Command is used to establish a data call.

| Command | Possible responses | |
|-------------|--------------------|-------------------------------------------|
| ATD<number> | CONNECT<speed> | If call is established |
| | BUSY | If called party is in another call |
| | NO ANSWER | If called party does not accept a call |
| | NO CARRIER | If there are problems to establish a call |

Defined values:

<speed>: Link baud rate between modem and network.

Remarks: Bearer type should be selected before (see AT+CBST). For phonebook dialling please see phonebook commands section.

Source: GSM 07.07/V.25ter/6.3.1

Implementation: complete

1.5.11 ATDL

Command is used to redial the last dialled number.

| Command | Possible responses | |
|---------|--------------------|-------------------------------------------|
| ATDL | CONNECT<speed> | If data call is established |
| | OK | If voice call is established |
| | BUSY | If called party is in another call |
| | NO ANSWER | If called party does not accept a call |
| | NO CARRIER | If there are problems to establish a call |

Defined values:

<speed>: Link baud rate between modem and network.

Remarks: Command uses the same type of connection (voice or data) as the last dialled connection.

Source: factory default

Implementation: complete

1.5.12 ATA

Command is used to accept an incoming call.

| Command | Possible responses | |
|---------|-----------------------|---------------------------------------------------------------------|
| ATA | OK CONNECT <speed> | If incoming call is a voice call If incoming call is a data call |

Defined values:

<speed> See ATD command.

Remarks: User should use command only if ATS0 equals zero.

Source: GSM 07.07/V.25ter/6.3.5

Implementation: complete

1.5.13 ATS0

The S0 parameter controls the automatic answering of an incoming call.

| Command | Possible responses | |
|----------|--------------------|--|
| ATS0=<n> | OK | |
| ATS0? | <n> | |

Defined values:

<n>: Automatic answer after <n> rings. A value of 0 disables automatic answering.

Remarks: none.

Source: GSM 07.07/V.25ter/6.3.5

Implementation: complete

1.5.14 ATH

Command is used to end a call.

| Command | Possible responses | |
|---------|--------------------|-------|
| ATH | OK | ERROR |

Remarks: none

Source: GSM 07.07/V.25ter/6.3.6

Implementation: complete

1.5.15 +++

Sequence is used to switch from on-line data mode to on-line command mode while in a data call.

| Command | Possible responses |
|---------|--------------------|
| +++ | OK |

Remarks: No <CR> is needed after the sequence. For another way to disconnect see AT&D command.
Source: factory default
Implementation: complete

1.5.16 ATO

Command is used to switch back from on-line command mode to on-line command data while in a data call.

| Command | Possible responses |
|---------|----------------------------|
| ATO | CONNECT <speed> ERROR |

Remarks: none
Source: GSM 07.07/V.25ter/6.3.7
Implementation: complete

1.5.17 AT+CBST

Command is used to select the bearer service type and the transparent or non-transparent mode for a data connection.

| Command | Possible responses |
|---------------------------|-----------------------------------------------------------------|
| +CBST=[<speed>,0,[,<ce>]] | OK |
| AT+CBST? | +CBST: <speed>,0,<ce> |
| AT+CBST=? | +CBST: (list of supported <speed>s),0,(list of supported <ce>s) |

Defined values:

| | | |
|----------|----|------------------------------------------------|
| <speed>: | 0 | Autobauding (automatic selection of the speed) |
| | 1 | 300 bps (V.21) |
| | 2 | 1200 bps (V.22) |
| | 4 | 2400 bps (V.22bis) |
| | 6 | 4800 bps (V.32) |
| | 7 | 9600 bps (V.32) |
| | 8 | specific |
| | 12 | 9600 bps (V.34) |
| | 14 | 14400 bps (V.34) |
| | 65 | 300 bps (V.110) |
| | 66 | 1200 bps (V.110) |
| | 68 | 2400 bps (V.110) |
| | 70 | 4800 bps (V.110) |
| | 71 | 9600 bps (V.110) |
| | 75 | 14400 bps (V.110) |

| | | |
|-------|---|-------------|
| <ce>: | 0 | Transparent |
|-------|---|-------------|

- | | |
|---|---------------------------|
| 1 | Non-transparent |
| 2 | Transparent preferred |
| 3 | Non-transparent preferred |

Remarks: none

Source: GSM 07.07/6.7

Implementation: complete

1.5.18 AT%C

This command enables or disables data compression negotiation.

| Command | Possible responses |
|---------|--------------------|
| AT%C<n> | OK |
| AT%C? | <n> |

Defined values:

- | | |
|------|---------------------------------------|
| <n>: | 0 no compression |
| | 2 V.42 compression, if supported |

Remarks: none

Source: factory default

Implementation: complete

1.5.19 AT+DS

This command enables or disables V.42 data compression.

| Command | Possible responses |
|-----------------------------|--------------------------------------------------|
| AT+DS=<dir>,<neg>,<P1>,<P2> | OK |
| AT+DS? | +DS: <dir>,<neg>,<P1>,<P2> |
| AT+DS=? | +DS: list of supported <dir>s,<neg>s,<P1>s,<P2>s |

Defined values:

- <dir> Specifies the desired direction(s) of operation of the data compression function; from the DTE point of view, (default is 3),

- | | |
|---|---------------------------------------|
| 0 | Negotiated ... no compression |
| 1 | Transmit only |
| 2 | Receive only |
| 3 | Both directions, accept any direction |

- <neg> Specifies whether or not the DCE should continue to operate if the desired result is not obtained, (default is 0),

| | |
|------------------------|-------------------------------------------------------------------------------------------------------------------|
| | 0 Do not disconnect if V.42bis is not negotiated by the remote DCE as specified in <dir> |
| | 1 Disconnect if V.42bis is not negotiated by the remote DCE as specified in <dir> |
| <P1> | Specifies the maximum number of dictionary entries which should be negotiated, range 512-4096, (default is 4096), |
| <P2> | Specifies the maximum string length to be negotiated, range 6-250, (default is 250), |
| Remarks: | none |
| Source: | factory default |
| Implementation: | complete |

1.5.20 AT\N

This command controls the preferred error correcting mode in a data connection. It can only be used for transparent data transmission.

If V42 feature is provided, the module authorises the LAPM error correction mode.

If MNP2 feature is provided, the module authorises the MNP error correction mode.

| Command | Possible responses |
|---------|--------------------|
| AT\N<n> | OK |
| AT\N? | |

Defined values:

| | |
|-----|-----------------------------------------------------------------------------|
| <n> | 0 Disables error correction mode |
| | 2 Selects an auto reliable mode (LAPM connection, then MNP connection) |
| | 4 Selects LAPM error correction mode |
| | 5 Selects MNP error correction mode |

Remarks: 2 and 4 are not implemented up to now.

Source: factory default

Implementation: complete

1.5.21 Remote disconnection

When the called party has ended a call the modem shows the final result code NO CARRIER.

1.6 Call information commands

1.6.1 AT+CR

Command controls whether or not intermediate result code +CR: <serv> is returned from the modem during connect negotiation of a data call.

| Command | Possible responses |
|--------------|-------------------------|
| +CR=[<mode>] | OK |
| AT+CR? | +CR: <mode> |
| AT+CR=? | +CR: (list of <modes>s) |

Defined values:

<mode>: 0 Disables reporting
1 Enables reporting

<serv>: ASYNC Asynchronous transparent
REL ASYNC Asynchronous non-transparent

Remarks: none

Source: GSM 07.07/6.9

Implementation: complete

1.6.2 AT+CRC

Command controls whether or not the normal RING message of an incoming call is replaced by an extended call indication using unsolicited result code +CRING: <type>.

| Command | Possible responses |
|---------------|--------------------------|
| +CRC=[<mode>] | OK |
| AT+CRC? | +CRC: <mode> |
| AT+CRC=? | +CRC: (list of <modes>s) |

Defined values:

<mode>: 0 Disables reporting
1 Enables reporting

<type>: ASYNC Asynchronous transparent
REL ASYNC Asynchronous non-transparent
VOICE Normal voice

Remarks: none

Source: GSM 07.07/6.11

Implementation: complete

1.6.3 AT+ILRR

Command is used to report the local DCE-DTE rate in extended format in any incoming or outgoing call before the CONNECT message. Intermediate result code +ILRR: <rate> is shown.

| Command | Possible responses |
|----------------|---------------------------|
| +ILRR=[<mode>] | OK |
| AT+ILRR? | +ILRR: <mode> |
| AT+ILRR=? | +ILRR: (list of <modes>s) |

Defined values:

| | |
|---------|---------------------------|
| <mode>: | 0 Disables reporting |
| | 1 Enables reporting |

Remarks: none

Source: GSM 07.07/4.3

Implementation: complete

1.6.4 AT+DR

Command determines whether or not the use of V42bis is informed in a data incoming or outgoing call. Intermediate result code +DR: <comp> is returned from the modem during connect negotiation of a data call.

| Command | Possible responses |
|--------------|-------------------------|
| +DR=[<mode>] | OK |
| AT+DR? | +DR: <mode> |
| AT+DR=? | +DR: (list of <modes>s) |

Defined values:

| | |
|---------|---------------------------|
| <mode>: | 0 Disables reporting |
| | 1 Enables reporting |

| | |
|---------|-------------------------------------------|
| <comp>: | NONE Data compression is not in use. |
|---------|-------------------------------------------|

| | |
|------|------------------------------------------|
| V42B | RecV.42bis is in use in both directions. |
|------|------------------------------------------|

| | |
|---------|---------------------------------------------------|
| V42B RD | Rec. V.42bis is in use in receive direction only. |
|---------|---------------------------------------------------|

| | |
|---------|----------------------------------------------------|
| V42B TD | Rec. V.42bis is in use in transmit direction only. |
|---------|----------------------------------------------------|

Remarks: The +DR intermediate result code, if enabled, is issued before the final result code, before the +ILRR intermediate report, and after the service report control +CR.

Source: factory default
Implementation: complete

1.7 Call setting commands

1.7.1 AT+CCFC

Command is used to set the call forwarding service.

| Command | Possible responses |
|--------------------------------------|-------------------------------------------------|
| +CCFC=<reason>,<mode> [,<number>] | OK When <mode>=2: +CCFC: <status>,<class> |
| AT+CCFC=? | +CCFC: (list of supported <reason>s) |

Defined values:

| | |
|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <reason>: | 0 Unconditional 1 Mobile busy 2 No reply 3 Not reachable 4 All call forwarding 5 All conditional call forwarding |
|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|

| | |
|---------|-------------------------------------------------------------------------------------------------|
| <mode>: | 0 Disable 1 Enable 2 Query status 3 Registration 4 Erasure |
|---------|-------------------------------------------------------------------------------------------------|

<number>: Telephone number to forward to.

<class> Is a sum of integers each representing a class of information (default 7 equals to all classes):

| | |
|---|-------|
| 1 | Voice |
| 2 | Data |
| 4 | Fax |

| | |
|-----------|------------------------------------|
| <status>: | 0 Not active 1 Active |
|-----------|------------------------------------|

Remarks: none
Source: GSM 07.07/7.10
Implementation: complete

1.7.2 AT+CCWA

Command is used to set the call waiting supplementary service.

| Command | Possible responses | |
|------------------------------------|--------------------------------------------------------------|-------------------|
| +CCWA=[<n>[,<mode> [,<class>]]] | OK When <mode>=2: +CCWA: <status>,<class> | +CME ERROR: <err> |
| AT+CCWA? | +CCWA: <n> | |
| AT+CCWA=? | +CCWA: (list of <n>s) | |

Defined values:

| | | |
|------------------------|--------------------------------------------------------------------------------------------------|--------------|
| <n> | (Sets/shows the result code presentation status): | |
| | 0 | Disable |
| | 1 | Enable |
| <mode> | (When <mode> parameter is not given, network is not interrogated): | |
| | 0 | Disable |
| | 1 | Enable |
| | 2 | Query status |
| <class> | Is a sum of integers each representing a class of information (default 7 equals to all classes): | |
| | 1 | Voice |
| | 2 | Data |
| | 4 | Fax |
| <status>: | 0 | Not active |
| | 1 | Active |
| Remarks: | none | |
| Source: | GSM 07.07/7.11 | |
| Implementation: | complete | |

1.7.3 AT+CLIP

Command is used to set and request the status of the calling line identification presentation service. Depending on the setting the number of the calling party will be shown as result code +CLIP: <number>,<type> on incoming calls (after every RING).

| Command | Possible responses |
|-------------|---------------------------------|
| +CLIP=[<n>] | OK |
| AT+CLIP? | +CLIP=<n>,<m> |
| AT+CLIP=? | +CLIP: (list of supported <n>s) |

Defined values:

<n> (Parameter sets/shows the result code presentation status):

- | | |
|---|---------|
| 0 | Disable |
| 1 | Enable |

<m> (Parameter shows the subscriber CLIP service status in the network):

- | | |
|---|---------------------------------|
| 0 | CLIP not provisioned |
| 1 | CLIP provisioned |
| 2 | Unknown (e.g. no network, etc.) |

<number>: String type phone number of format specified by <type>.

<type>: Type of address octet in integer format.

Remarks: none

Source: GSM 07.07/7.6

Implementation: complete

1.7.4 AT+CLIR

Command is used to set and request the status of the calling line identification restriction service. Depending on the setting the own number is presented to the called party or not.

| Command | Possible responses |
|-------------|---------------------------------|
| +CLIR=[<n>] | OK |
| AT+CLIR? | +CLIR=<n>,<m> |
| AT+CLIR=? | +CLIR: (list of supported <n>s) |

Defined values:

<n> (Parameter sets the adjustment for outgoing calls):

- | | |
|---|------------------------------------------------------------------------------------------------------------------|
| 0 | Presentation indicator is used according to the subscription of the CLIR service (as with the SIM card contract) |
| 1 | CLIR invocation (number will not be transmitted) |
| 2 | CLIR suppression (number will be transmitted) |

<m> (Parameter shows the subscriber CLIR service status in the network):

- 0 CLIR not provisioned
- 1 CLIR provisioned in permanent mode
- 2 Unknown (e.g. no network, etc.)
- 3 CLIR temporary mode presentation restricted
- 4 CLIR temporary mode presentation allowed

Remarks: none

Source: GSM 07.07/7.7

Implementation: complete

1.7.5 AT+COLP

Command is used to set and request the status of the connected line identification presentation. Depending on the setting the number of the called party will be shown as result code +COLP: <number>,<type> on outgoing calls.

| Command | Possible responses |
|-----------|---------------------------------|
| +COLP=<n> | OK |
| AT+COLP? | +COLP=<n>,<m> |
| AT+COLP=? | +COLP: (list of supported <n>s) |

Defined values:

<n> (Parameter sets/shows the result code presentation status):

- 0 Disable
- 1 Enable

<m> (Parameter shows the subscriber COLP service status in the network):

- 0 COLP not provisioned
- 1 COLP provisioned
- 2 Unknown (e.g. no network, etc.)

<number>: String type phone number of format specified by <type>.

<type>: Type of address octet in integer format.

Remarks: not available in most networks

Source: GSM 07.07/7.8

Implementation: complete

1.8 Phonebook commands

1.8.1 AT+CPBS

Command selects phonebook memory storage. The SIM card is the only storage in the A2D module.

| Command | Possible responses | |
|-----------------|---------------------------------------|-------------------|
| +CPBS=<storage> | OK | +CME ERROR: <err> |
| +CPBS? | +CPBS: <storage>[,<used>,<total>] | +CME ERROR: <err> |
| +CPBS=? | +CPBS: (list of supported <storage>s) | |

Defined values:

<storage>:
 "SM" SIM abbrev. dialling phonebook
 "FD" SIM fixed dialling phonebook
 "ON" SIM own numbers phonebook

<used>:
 Integer type value indicating the number of used locations in selected memory.

<total>:
 Integer type value indicating the total number of locations in selected memory.

Remarks: none

Source: GSM 07.07/8.11

Implementation: complete

1.8.2 AT+CPBR

Command is used to read a special entry or a range of entries from the phonebook memory storage.

| Command | Possible responses | |
|---------------------------|-----------------------------------------------------------------------------------------------------|-------------------|
| +CPBR=<index1>[,<index2>] | +CPBR: <index1>,<number>,<type>,<text> <CR><LF> +CPBR: <index2>,<number>,<type>,<text>] | +CME ERROR: <err> |
| +CPBR=? | +CPBR: (list of supported <index>s),<nlength>,<tlength> | +CME ERROR: <err> |

Defined values:

<index1>, <index2>, <index>:
 Integer type values in the range of location numbers of phonebook memory.

<number>:
 String type phone number of format <type>.

| | |
|------------------------|---------------------------------------------------------------------------------------------------------------------|
| <type>: | Type of address octet in integer format. |
| <text>: | String type field of maximum length <tlength>; character set as specified by command Select TE Character Set +CSCS. |
| <nlength>: | Integer type value indicating the maximum length of field <number>. |
| <tlength>: | Integer type value indicating the maximum length of field <text>. |
| Remarks: | none |
| Source: | GSM 07.07/8.12 |
| Implementation: | complete |

1.8.3 AT+CPBF

Command is used to find a phonebook entry using a search-string.

| Command | Possible responses | |
|------------------|-------------------------------------------------------------------------------------------------|------------------|
| +CPBF=<findtext> | +CPBF: <index1>,<number>,<type>,<text> <CR><LF>+CPBF: <index2>,<number>,<type>,<text>] | +CME ERROR:<err> |
| +CPBF=? | +CPBF: <nlength>,<tlength> | +CME ERROR:<err> |

Defined values:

| | |
|---------------------|---------------------------------------------------------------------------------------------------------------------|
| <index1>, <index2>: | Integer type values in the range of location numbers of phonebook memory. |
| <number>: | String type phone number of format <type>. |
| <type>: | Type of address octet in integer format. |
| <findtext>,<text>: | String type field of maximum length <tlength>; character set as specified by command Select TE Character Set +CSCS. |
| <nlength>: | Integer type value indicating the maximum length of field <number>. |

<tlength>: Integer type value indicating the maximum length of field <text>.

Remarks: none
Source: GSM 07.07/8.13
Implementation: complete

1.8.4 AT+CPBW

Command is used to write a phonebook entry to a special place in the phonebook memory storage.

| Command | Possible responses | |
|-----------------------------------------------|---------------------------------------------------------------------------------------|-------------------|
| +CPBW=[<index> [,<number> [<type>,[<text>]]]] | OK | +CME ERROR: <err> |
| +CPBW=? | +CPBW: (list of supported <index>s), <nlength>, (list of supported <type>s),<tlength> | +CME ERROR: <err> |

Defined values:

<index>: Integer type values in the range of location numbers of phonebook memory.

<number>: String type phone number of format <type>.

<type>: Type of address octet in integer format.

<text>: String type field of maximum length <tlength>; character set as specified by command Select TE Character Set +CSCS.

<nlength>: Integer type value indicating the maximum length of field <number>.

<tlength>: Integer type value indicating the maximum length of field <text>.

Remarks: none
Source: GSM 07.07/8.14
Implementation: complete

1.9 Message handling commands

1.9.1 AT+CSCA

Command is used to set the service centre address. Mobile originated messages are transmitted through these service centre.

| Command | Possible responses |
|-----------------------|----------------------|
| +CSCA=<sca>[,<tosca>] | OK |
| +CSCA? | +CSCA: <sca>,<tosca> |
| +CSCA=? | OK |

Defined values:

<sca>: GSM 04.11 RP service centre address Address-Value field in string format

<tosca>: GSM 04.11 RP service centre address Type-of-Address octet in integer format

Remarks: In PDU mode (at+cmgf=0) this command is needed only when the length of the SMSC address coded into <pdu> parameter equals zero.

Source: GSM 07.05/3.3.1

Implementation: complete

1.9.2 AT+CMGL

Command is used to read selected messages from the SIM card storage.

- Text mode:

| Command | Possible responses |
|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| +CMGL[=<stat>] | +CMGL: <index>,<stat>,<oa/da> „[<scts>][,<tooa/toda>,<length>]<CR><LF><data>[<CR><LF>] +CMGL: <index>,<stat>,<da/oa> „[<scts>][,<tooa/toda>,<length>]<CR><LF><data>[...]] |
| +CMGL=? | +CMGL: (list of supported <stat>s) |

Defined values:

<stat> String type (default "REC UNREAD"); indicates the status of message in memory:

| | |
|--------------|-----------------------------------------------|
| "REC UNREAD" | Received unread message (i.e. new message) |
| "REC READ" | Received read message |

| | | |
|----------|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | "STO UNSENT" | Stored unsent message |
| | "STO SENT" | Stored sent message |
| | "ALL" | All messages |
| <index> | | Integer type; value in the range of location numbers supported by the associated memory |
| <oa> | | GSM 03.40 TP-Originating-Address Address-Value field in string format |
| <da> | | GSM 03.40 TP-Destination-Address Address-Value field in string format |
| <scts> | | GSM 03.40 TP-Service-Centre-Time-Stamp in time-string format |
| <toda> | | GSM 04.11 TP-Destination-Address Type-of-Address octet in integer format (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129) |
| <tooa> | | GSM 04.11 TP-Originating-Address Type-of-Address octet in integer format (default refer <toda>) |
| <length> | | Integer type value indicating the length of the message body <data> in characters |
| <data> | | GSM 03.40 TP-User-Data in text mode responses |

- PDU mode:

| Command | Possible responses |
|----------------|-------------------------------------------------------------------------------------------------------------------|
| +CMGL[=<stat>] | +CMGL: <index>,<stat>,,<length><CR><LF> <pdu> [<CR><LF>+CMGL:<index>,<stat>,,<length><CR><LF><pdu>[...]] |
| +CMGL=? | +CMGL: (list of supported <stat>s) |

Defined values:

| | |
|--------|---------------------------------------------------------------------|
| <stat> | Integer type (default 0) indicates the status of message in memory: |
| 0 | Received unread message (i.e. new msg.) |
| 1 | Received read message |
| 2 | Stored unsent message |
| 3 | Stored sent message |
| 4 | All messages |

| | |
|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| <index> | See text mode |
| <length> | Integer type value the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length); |
| <pdu> | GSM 04.11 SC address followed by GSM 03.40 TPDU in hexadecimal format |
| Remarks: | none |
| Source: | GSM 07.05/3.4.2,4.1 |
| Implementation: | complete |

1.9.3 AT+CMGR

Command is used to read one messages from the SIM card storage.

- Text mode:

| Command | Possible responses | |
|---------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|
| +CMGR=<index> | if SMS-DELIVER: +CMGR: <stat>,<oa>,,<scts>[,<tooa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>] <CR><LF><data> if SMS-SUBMIT: +CMGR: <stat>,<da>[,<toda>,<fo>,<pid>,<dcs>[,<vp>],<sca>,<tosca>,<length>] <CR><LF><data> | +CMS ERROR: <err> |
| +CMGR=? | OK | |

Defined values:

<stat> String type (default "REC UNREAD"); indicates the status of message in memory:

| | |
|--------------|-----------------------------------------------|
| "REC UNREAD" | Received unread message (i.e. new message) |
| "REC READ" | Received read message |
| "STO UNSENT" | Stored unsent message |
| "STO SENT" | Stored sent message |
| "ALL" | All messages |

<index> Integer type; value in the range of location numbers supported by SIM memory

<oa> GSM 03.40 TP-Originating-Address Address-Value field in string format

<da> GSM 03.40 TP-Destination-Address Address-Value field in string format

| | |
|----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <scts> | GSM 03.40 TP-Service-Centre-Time-Stamp in time-string format |
| <toda> | GSM 04.11 TP-Destination-Address Type-of-Address octet in integer format (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129) |
| <tooa> | GSM 04.11 TP-Originating-Address Type-of-Address octet in integer format (default refer <toda>) |
| <fo> | First octet of GSM 03.40 SMS-DELIVER or SMS-SUBMIT (default 17) |
| <pid> | GSM 03.40 TP-Protocol-Identifier in integer format (default 0) |
| <dcs> | GSM 03.38 SMS Data Coding Scheme (default 0) |
| <vp> | Depending on SMS-SUBMIT <fo> setting: GSM 03.40 TP-Validity-Period either in integer format (default 167) or in time-string format |
| <length> | Integer type value indicating the length of the message body <data> in characters |
| <data> | GSM 03.40 TP-User-Data in text mode responses |

- PDU mode:

| Command | Possible responses | |
|---------------|------------------------------------|------------------|
| +CMGR=<index> | +CMGR:<stat>,<length><CR><LF><pdu> | +CMS ERROR:<err> |
| +CMGR=? | OK | |

Defined values:

| | | |
|---------|---------------------------------------------------------------------|--------------------------------------------|
| <stat> | Integer type (default 0) indicates the status of message in memory: | |
| | 0 | Received unread message (i.e. new message) |
| | 1 | Received read message |
| | 2 | Stored unsent message |
| | 3 | Stored sent message |
| | 4 | All messages |
| <index> | See text mode | |

| | |
|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| <length> | Integer type value the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length); |
| <pdu> | GSM 04.11 SC address followed by GSM 03.40 TPDU in hexadecimal format |
| Remarks: | none |
| Source: | GSM 07.05/3.4.3,4.2 |
| Implementation: | complete |

1.9.4 AT+CMGS

Command is used to send a message to the service centre.

- Text mode:

| Command | Possible responses | |
|---------------------------------------------------------------------|--------------------|-------------------|
| +CMGS=<da>[,<toda>]<CR> text is entered<ctrl-Z/ESC> | +CMGS: <mr> | +CMS ERROR: <err> |
| +CMGS=? | OK | |

Defined values:

| | |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <da> | GSM 03.40 TP-Destination-Address Address-Value field in string format |
| <toda> | GSM 04.11 TP-Destination-Address Type-of-Address octet in integer format (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129) |
| <mr> | GSM 03.40 TP-Message-Reference in integer format |

- PDU mode:

| Command | Possible responses | |
|--------------------------------------------------------|--------------------|-------------------|
| +CMGS=<length><CR> PDU is given <ctrl-Z/ESC> | +CMGS: <mr> | +CMS ERROR: <err> |
| +CMGS=? | OK | |

Defined values:

| | |
|----------|-------------------------------------------------------------------------------------------------------------------------------------------|
| <length> | Integer type value the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length); |
| <pdu> | GSM 04.11 SC address followed by GSM 03.40 TPDU in hexadecimal format |
| <mr> | See text mode |

| | |
|------------------------|--------------------------------------------------------------------------------------------------------------------------------|
| Remarks: | When the length octet of the SMSC address equals zero, the SMSC address set with command Service Centre Address +CSCA is used. |
| Source: | GSM 07.05/3.5.1,4.3 |
| Implementation: | complete |

1.9.5 AT+CMSS

Command is used to send a message from the SIM card storage to the service centre.

| Command | Possible responses | |
|-------------------------------|--------------------|-------------------|
| +CMSS=<index>[,<da>[,<toda>]] | +CMSS: <mr> | +CMS ERROR: <err> |
| +CMSS=? | OK | |

Defined values:

| | |
|---------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <index> | integer type; value in the range of location numbers supported by SIM memory |
| <da> | GSM 03.40 TP-Destination-Address Address-Value field in string format |
| <toda> | GSM 04.11 TP-Destination-Address Type-of-Address octet in integer format (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129) |
| <mr> | GSM 03.40 TP-Message-Reference in integer format |

| | |
|------------------------|-----------------|
| Remarks: | none |
| Source: | GSM 07.05/3.5.2 |
| Implementation: | complete |

1.9.6 AT+CMGW

Command is used to write a message to the SIM card storage.

- Text mode:

| Command | Possible responses | |
|----------------------------------------------------------------------------------|--------------------|-------------------|
| +CMGW=<oa/da>[,<tooa,toda>[,<stat>]] <CR> text is entered <ctrl-Z/ESC> | +CMGW: <index> | +CMS ERROR: <err> |
| +CMGW=? | OK | |

Defined values:

| | |
|---------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <oa> | GSM 03.40 TP-Originating-Address Address-Value field in string format |
| <tooa> | GSM 04.11 TP-Originating-Address Type-of-Address octet in integer format (default refer <toda>) |
| <da> | GSM 03.40 TP-Destination-Address Address-Value field in string format |
| <toda> | GSM 04.11 TP-Destination-Address Type-of-Address octet in integer format (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129) |
| <index> | Integer type; value in the range of location numbers supported by SIM memory |
| <stat> | String type (default "REC UNREAD"); indicates the status of message in memory: "REC UNREAD" Received unread message (i.e. new message) "REC READ" Received read message "STO UNSENT" Stored unsent message "STO SENT" Stored sent message "ALL" All messages |

- PDU mode:

| Command | Possible responses | |
|-----------------------------------------------------------------------|--------------------|-------------------|
| +CMGW=<length>[,<stat>]<CR> PDU is given <ctrl-Z/ESC> | +CMGW:<index> | +CMS ERROR: <err> |
| +CMGW=? | OK | |

Defined values:

| | |
|----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <length> | Integer type value the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length); |
| <stat> | Integer type (default 0) indicates the status of message in memory: 0 Received unread message (i.e. new msg.) 1 Received read message 2 Stored unsent message 3 Stored sent message 5 All messages |

| | |
|------------------------|--------------------------------------------------------------------------------------------------------------------------------|
| <index> | See text mode |
| <pdu> | GSM 04.11 SC address followed by GSM 03.40 TPDU in hexadecimal format |
| Remarks: | When the length octet of the SMSC address equals zero, the SMSC address set with command Service Centre Address +CSCA is used. |
| Source: | GSM 07.05/3.5.3,4.4 |
| Implementation: | complete |

1.9.7 AT+CMGD

Command is used to delete a message from the SIM card storage.

| Command | Possible responses | |
|---------------|--------------------|-------------------|
| +CMGD=<index> | OK | +CMS ERROR: <err> |
| +CMGD=? | OK | |

Defined values:

| | |
|------------------------|------------------------------------------------------------------------------|
| <index> | integer type; value in the range of location numbers supported by SIM memory |
| Remarks: | none |
| Source: | GSM 07.05/3.5.4 |
| Implementation: | complete |

1.10 Message setting commands

1.10.1 AT+CSMS

Command is used to select messaging services. It also shows supported services, where <mt> stands for mobile terminated messages, <mo> for mobile originated messages and <bm> stands for broadcast type messages.

| Command | Possible responses | |
|-----------------|---------------------------------------|-------------------|
| +CSMS=<service> | +CSMS: <mt>,<mo>,<bm> | +CMS ERROR: <err> |
| +CSMS? | +CSMS: <service>,<mt>,<mo>,<bm> | |
| +CSMS=? | +CSMS: (list of supported <service>s) | |

Defined values:

| | | |
|-------------------|---------|-------------------------------------------------------------|
| <service>: | 0 | GSM 03.40 and 03.41 (GSM standards for SMS, Cell Broadcast) |
| | 1...127 | Reserved |
| | 128... | Manufacturer specific |
| <mt>, <mo>, <bm>: | 0 | Type not supported |

| | |
|---|----------------|
| 1 | Type supported |
|---|----------------|

Remarks: none
Source: GSM 07.05/3.2.1
Implementation: complete

1.10.2 AT+CPMS

Command is used to select memory storage that will be used for reading <mem1> and writing <mem2> short messages to and for writing broadcast <mem3> to.

| Command | Possible responses |
|--------------------------------|----------------------------------------------------------------------------------------------------------------|
| +CPMS=<mem1>[,<mem2>[,<mem3>]] | +CPMS: <used1>,<total1>,<used2>,<total2>,<used3>,<total3> +CMS ERROR: <err> |
| +CPMS? | +CPMS: <mem1>,<used1>,<total1>, <mem2>,<used2>,<total2>, <mem3>,<used3>,<total3> +CMS ERROR: <err> |
| +CPMS=? | +CPMS: (list of supported <mem1>s) ,(list of supported <mem2>s) ,(list of supported <mem3>s) |

Defined values:

<mem1> String type; memory from which messages are read and deleted (commands List Messages +CMGL, Read Message +CMGR and Delete Message +CMGD); defined values:

"SM" SIM message storage
 "BM" Broadcast message storage

<mem2> String type; memory to which writing and sending operations are made (commands Send Message from Storage +CMSS and Write Message to Memory +CMGW)

<mem3> String type; memory to which received SMs are preferred to be stored (unless forwarded directly to TE; refer command New Message Indications +CNMI); refer <mem1> for defined values

<total1> Integer type; total number of message locations in <mem1>

<total2> Integer type; total number of message locations in <mem2>

<total3> Integer type; total number of message locations in <mem3>

| | |
|------------------------|------------------------------------------------------|
| <used1> | Integer type; number of messages currently in <mem1> |
| <used2> | Integer type; number of messages currently in <mem2> |
| <used3> | Integer type; number of messages currently in <mem3> |
| Remarks: | None |
| Source: | GSM 07.05/3.2.2 |
| Implementation: | complete |

1.10.3 AT+CMGF

Command is used to select format for incoming and outgoing messages.

| Command | Possible responses |
|--------------|------------------------------------|
| +CMGF=<mode> | OK |
| +CMGF? | +CMGF: <mode> |
| +CMGF=? | +CMGF: (list of supported <mode>s) |

Defined values:

| | |
|---------|-------------|
| <mode>: | 0 PDU mode |
| | 1 Text mode |

| | |
|------------------------|-----------------|
| Remarks: | none |
| Source: | GSM 07.07/3.2.3 |
| Implementation: | complete |

1.10.4 AT+CSMP

Command is used to set additional parameters for text mode messages.

| Command | Possible responses |
|------------------------------------|------------------------------|
| +CSMP=<fo>[,<vp>[,<pid>[,<dcs>]]]] | OK |
| +CSMP? | +CSMP: <fo>,<vp>,<pid>,<dcs> |
| +CSMP=? | OK |

Defined values:

| | |
|--------|----------------------------------------------------------------------------------------------|
| <fo>: | First octet of GSM 03.40 SMS-DELIVER, SMS-SUBMIT in integer format (default 17) |
| <vp>: | GSM 03.40 TP-Validity-Period either in integer format (default 167) or in time-string format |
| <pid>: | GSM 03.40 TP-Protocol-Identifier in integer format (default 0) |

<dcs>: GSM 03.38 SMS Data Coding Scheme (default 0) in integer format

Remarks: none
Source: GSM 07.05/3.3.2
Implementation: complete

1.10.5 AT+CSDH

Command controls whether detailed header information is shown in text mode result codes.

| Command | Possible responses |
|---------------|------------------------------------|
| +CSDH=<show>] | OK |
| +CSDH? | +CSDH: <show> |
| +CSDH=? | +CSDH: (list of supported <show>s) |

Defined values:

| | | |
|---------|---|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <show>: | 0 | Do not show header values defined in commands +CSCA and +CSMP (<sca>, <tosca>, <fo>, <vp>, <pid> and <dcs>) nor <length>, <toda> or <tooa> in +CMT, +CMGL, +CMGR result codes for SMS/PP text mode |
| | 1 | Show the values in result codes |

Remarks: none
Source: GSM 07.05/3.3.3
Implementation: complete

1.10.6 AT+CSCS

Command is used to set and request the implemented character set. Incoming characters are converted to the current used set.

| Command | Possible responses |
|----------------|-------------------------------------|
| +CSCS=<chset>] | OK |
| +CSCS? | +CSCS: <chset> |
| +CSCS=? | +CSCS: (list of supported <chset>s) |

Defined values:

| | |
|----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <chset>: | (conversion schemes listed here are supported by the Falcom A2D) “GSM” GSM default alphabet (GSM 03.38) “PCCP437” PC character set Code Page 437 |
|----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|

Remarks: none
Source: GSM 07.07/5.5
Implementation: complete

1.10.7 AT+CNMI

Command selects the procedure, how receiving of new messages from the network is indicated to TE is active (e.g. DTR signal ON). If TE is inactive (e.g. DTR signal is OFF), message receiving should be done as specified in GSM 03.38. <mode> controls the processing of unsolicited result codes specified within this command, <mt> sets the result code indication routing for SMS DELIVERS, <bm> for CBMs and <ds> for SMS STATUS REPORTS. <bfr> defines the handling method for buffered result codes when <mode> 1, 2 or 3 is enabled. If ME does not support requested item (although TA does) final result code +CMS ERROR: <err> returned. Look at chapter Message Service Failure Result Code for a list of <err> values. Test_command gives the settings supported by the TA as compound values.

NOTE: Command selects message service +CSMS should be used to detect ME support of mobile terminated SMS and CBM.

| Command | Possible responses |
|---------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| +CNMI=[<mode>[,<mt>[,<bm>[,<ds>[,<bfr>]]]]] | +CMS Error: <err> |
| +CNMI? | +CNMI: <mode>,<mt>,<bm>,<ds>,<bfr> |
| +CNMI = ? | +CNMI: (list of supported <mode>s), (list of supported <mt>s), (list of supported <bm>s), (list of supported <ds>s), (list of supported <bfr>s) |

Defined Values:

Only <mode>=2 is supported.

Any other value for <mode> (0,1 or 3) is accepted (return code will be *OK*), but the processing of unsolicited result codes will be the same than for <mode>=2.

- | | | |
|---------|---|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <mode>: | 0 | Buffer unsolicited result codes in the TA. If TA result code buffer is full, indications can be buffered in some other places or the oldest indications may be discarded and replaced with the new received indications. |
| | 1 | Discard indication and reject new received message unsolicited result codes when TA-TE link is reserved (e.g. in online data mode). Otherwise forward them directly to the TE. |
| | 2 | Buffer unsolicited result codes in the TA when TA TE link is reserved (e.g. in online data mode) and flush them to the TE after reservation. Otherwise forward them directly to the TE. |

- 3 Forward unsolicited result codes directly to the TE. TA-TE link specific inband technique used embed result codes and data when TA is in on-line data mode.

<mt>: (**NOTE:** the rules for storing received SMS depend on message class, preferred memory storage (+CPMS) setting and this value)

- 0 No SMS-DELIVER indications are routed to the TE.

- 1 Indication of SMS-DELIVER is routed to the TE using unsolicited result code:

+ CMTI: <mem>, <index>

- 2 SMS-DELIVERS (except class 2 messages) are routed directly to the TE unsolicited result code:

- PDU mode enabled:

+ CMT: [<alpha>],<length>
<CR><LF> <pdu>

- Text mode enabled (about parameters in italics, refer command Show Text Mode Parameters +CSDH):

+CMT: <oa>,[<alpha>],<scts>
[,<tooa>,<fo>,<pid>,<dcs>,<sca>,
<tosca>,<length>]<CR><data>

Class 2 messages result in indication as defined in <mt>=1.

- 3 Class 3 SMS-Delivers are routed directly to TE using unsolicited result codes defined in <mt> = 2.
Messages of other classes result in indication as defined in <mt>= 1.

| | |
|-------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <mt> | Receiving procedure for different message classes (GSM 03.38 SM Data Coding Scheme) |
| 0 | Class 0: as in GSM 03.38, but use <mem> as preferred memory if message is tried to be stored Class 1: as in GSM 03.38 but use <mem3> as preferred memory Class 2: as in GSM 03.38 Class 3: as class1 |

| | |
|---|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 | As $<\text{mt}> = 0$ but send indication if message stored successfully |
| 2 | Class 0: as in GSM 03.38, but always route message to TE do not try to store it in memory Class 1: route message to TE Class 2: as in GSM 03.38, but also send indication if message stored successfully Class 3: route message to TE |
| 3 | Class 0,1,2: as $<\text{mt}> = 1$ Class 3: route message to TE |

$<\text{bm}>$: (the rules for storing received CBMs depend on its message class, the setting of Select CBM Types (+CSCB) and this value)

0 No CBM indications are routed to the TE

1 Indication of new CBM is routed to the TE using unsolicited result code:

+CBMI: $<\text{mem}>,<\text{index}>$

2 New CBMs are routed directly to the TE using unsolicited result code

- PDU mode enabled:

+ CBM: $<\text{length}><\text{CR}><\text{LF}><\text{pdu}>$

- Text mode enabled:

+ CBM: $<\text{sn}>,<\text{mid}>,<\text{dcs}>,<\text{page}>,<\text{CR}><\text{LF}><\text{data}>$

3 Class 3 CBMs are routed directly to TE using unsolicited result codes defined in $<\text{bm}> = 2$. Messages of other classes result in indication as defined in $<\text{bm}> = 1$.

| | |
|---------------|--------------------------------------------------------------------------------------|
| $<\text{bm}>$ | Receiving procedure for different message classes (GSM 03.38 CBM Data Coding Scheme) |
| 0 | Store message to "BM" (or some manufacturer specific memory) |
| 1 | As $<\text{bm}> = 0$ but send indication if message stored successfully |
| 2 | Route message to TE |
| 3 | Class 0,1,2: as $<\text{bm}> = 1$ Class 3: route message to TE |

$<\text{ds}>$: 0 No SMS- STATUS-REPORTs are routed to the TE

- 1 SMS-STATUS-REPORTs are routed to the TE using unsolicited result code
- PDU mode enabled:
+CDS: <length><CR><LF><pdu>
 - Text mode enabled:
+CDS: <fo>,<mr>,[<ra>],[<tora>],
<scts>,<dt>,<st>
- <bfr>: 0 TA buffer of unsolicited result codes defined within this command is flushed to the TE when <mode> 1...3 is entered (OK response shall be given before flushing the codes).
- 1 TA buffer of unsolicited result codes defined within this command is cleared when <mode> 1..3 is entered.

Remarks: none
Source: GSM 07.05/3.3.3
Implementation: complete

1.10.8 AT+CSCB

Command is used to set parameters of how broadcast messages are to be received.

| Command | Possible responses |
|----------------------------------|-------------------------------------|
| +CSCB=[<mode>[,<mids>[,<dcss>]]] | OK |
| +CSCB? | +CSCB: <mode>,<mids>,<dcss> |
| +CSCB=? | +CSCB: (list of supported <modes>s) |

Defined values:

- <mode>: 0 Message types specified in <mids> and <dcss> are accepted
- 1 Message types specified in <mids> and <dcss> are not accepted
- <mids>: String type; all different possible combinations of CBM message identifiers (refer <mid>) (default is empty string); e.g. "0,1,5,320-478,922"

<dcss>: String type; all different possible combinations of CBM data coding schemes (refer <dcs>) default is empty string); e.g. "0-3,5"

Remarks: none

Source: GSM 07.05/3.3.4

Implementation: complete

1.11 Fax class 1 commands

The fax service provided by the module is class 1 compatible. However only the core commands defined by ITU T.31 are supported. It means that commands like AT+FAR, +FCC, etc are not supported. **Autobausing has to be enabled to set up the module for fax.** All set commands below (except AT+FCLASS) return an ERROR response code if they are not issued during the communication.

1.11.1 AT+FCLASS

This command puts the module into a particular mode of operation (data or fax).

| Command | Possible responses |
|----------------|-----------------------------------|
| AT+FCLASS= <n> | OK |
| AT+FCLASS? | +FCLASS: <n> |
| AT+FCLASS=? | +FCLASS: (list of supported <n>s) |

Defined values:

| | | |
|-----|---|-------------|
| <n> | 0 | Data |
| | 1 | Fax class 1 |
| | 2 | Fax class 2 |

Remarks: none

Source:

Implementation: complete

1.11.2 AT+FTM

This command sets the fax transmit speed.

| Command | Possible responses |
|----------------|------------------------------|
| AT+FTM=<speed> | OK |
| AT+FTM=? | (list of supported <speed>s) |

Defined values:

| | | |
|---------|----|-------------------------------------|
| <speed> | 24 | 2400 bps (Modem type : V.27ter) |
| | 48 | 4800 bps (Modem type : V.27ter) |
| | 72 | 7200 bps (Modem type : V.29) |
| | 73 | 7200 bps (long) (Modem type : V.17) |

| | |
|-----|---------------------------------------|
| 74 | 7200 bps (short) (Modem type : V.17) |
| 96 | 9600 bps (Modem type : V.29) |
| 97 | 9600 bps (long) (Modem type : V.17) |
| 98 | 9600 bps (short) (Modem type : V.17) |
| 121 | 12000 bps (long) (Modem type : V.17) |
| 122 | 12000 bps (short) (Modem type : V.17) |
| 145 | 14400 bps (long) (Modem type : V.17) |
| 146 | 14400 bps (short) (Modem type : V.17) |

Remarks: none**Source:****Implementation:** complete

1.11.3 AT+FRM

This command sets the fax receive speed. The speed values are the same than these of +FTM command.

| Command | Possible responses |
|----------------|------------------------------|
| AT+FRM=<speed> | OK |
| AT+FRM=? | (list of supported <speed>s) |

Remarks: none**Source:****Implementation:** complete

1.11.4 AT+FTH

This command sets the fax transmit speed, using the HDLC protocol.

| Command | Possible responses |
|----------------|--------------------|
| AT+FTH=<speed> | OK |
| AT+FTH=? | (3) |

Remarks: <speed> can only take the value 3, which corresponds to V.21 channels 300 bps.**Source:****Implementation:** complete

1.11.5 AT+FRH

This command sets the fax receive speed, using the HDLC protocol.

| Command | Possible responses |
|----------------|--------------------|
| AT+FRH=<speed> | OK |
| AT+FRH=? | (3) |

Remarks: <speed> can only take the value 3, which corresponds to V.21 channels 300 bps.

Source:**Implementation:** complete**1.11.6 AT+FTS**

This command stops the transmission for the specified period.

| Command | Possible responses |
|------------|--------------------------|
| AT+FTS=<n> | OK |
| AT+FTS=? | (list of supported <n>s) |

Defined Values:

<n> silence period (units of 10 ms).

Remarks: none

Source:

Implementation: complete

1.11.7 AT+FRS

This command causes the modem to stop listening from the network and report back to the DTE after the specified period. It is aborted if any character is received from the application.

| Command | Possible responses |
|------------|--------------------------|
| AT+FRS=<n> | OK |
| AT+FRS=? | (list of supported <n>s) |

Defined Values:

<n> units of 10ms

Remarks: none

Source:

Implementation: complete

1.12 Fax class 2 commands

If the feature is present, the commands +FDT, +FDR, +FET, +FPTS and +FK have to be used in communication only.

The other commands +FBOR, +FBUF, FCQ, +FCR, +FDCC, +FDIS, +FLID and +FPHCTO can not be used in communication.

1.12.1 AT+FDT

This command prefixes data transmission.

| Command | Possible responses |
|---------|--------------------|
| AT+FDT | OK |

Remarks: none
Source:
Implementation: complete

1.12.2 AT+FDR

This command initiates data reception.

| Command | Possible responses |
|---------|--------------------|
| AT+FDR | OK |

Remarks: none
Source:
Implementation: complete

1.12.3 AT+FET

This command punctuates page and document transmission after +FDT commands. It indicates that the current page is complete, and whether or not there are additional pages to be sent.

| Command | Possible responses |
|--------------|--------------------|
| AT+FET=<ppm> | OK |

Defined values:

| | | |
|-------|---|---------------------------------------|
| <ppm> | 0 | Another page next, same document |
| | 1 | Another document next |
| | 2 | No more pages or documents |
| | 3 | Another partial page next |
| | 4 | Another page, procedure interrupt |
| | 5 | Another document, procedure interrupt |
| | 6 | All done, procedure interrupt |

Remarks: The remote station should respond with:
+FPTS, <ppr>.

Source:
Implementation: complete

1.12.4 AT+FPTS

This command sets post page transfer response.

| Command | Possible responses |
|---------------|--------------------|
| AT+FPTS=<ppr> | OK |

Defined values:

| | | |
|-------|---|------------------------------|
| <ppr> | 1 | Page good |
| | 2 | Page bad: retrain requested |
| | 3 | Page good: retrain requested |

| | |
|---|--------------------------------|
| 4 | Page bad: interrupt requested |
| 5 | Page good: interrupt requested |

Remarks: none**Source:****Implementation:** complete

1.12.5 AT+FK

This command causes the module to terminate the session.

| Command | Possible responses |
|---------|--------------------|
| AT+FK | OK |

Remarks: none**Source:****Implementation:** complete

1.12.6 AT+FBOR

This command sets the bit order for negotiation and fax page transfer. The order is related to the bit order or radio link.

| Command | Possible responses |
|-------------|--------------------------|
| AT+FBOR=<n> | OK |
| AT+FBOR=? | (list of supported <n>s) |

Defined values:

| | | |
|-----|---|----------------------------------------------------------------------|
| <n> | 0 | Same bit order for negotiation and page transfer |
| | 1 | Same bit order for negotiation, Reserved bit order for page transfer |
| | 2 | Reserved bit order for negotiation, Same bit order for page transfer |
| | 3 | Reserved bit order for negotiation and page transfer |

Remarks: none**Source:****Implementation:** complete

1.12.7 AT+FBUF

This command request the size of the exchange buffer between the modem and the fax application. Only the read command is supported.

| Command | Possible responses |
|----------|--------------------|
| AT+FBUF? | <current value> |

Remarks: none

Source:**Implementation:** complete**1.12.8 AT+FCQ**

This command controls the Copy Quality checking for receiving faxes.

| Command | Possible responses |
|------------|--------------------|
| AT+FCQ=<n> | OK |
| AT+FCQ=? | (0) |

Remarks: none**Source:****Implementation:** complete**1.12.9 AT+FCR**

This command controls the capability of the modem to accept incoming faxes.

| Command | Possible responses |
|------------|--------------------------|
| AT+FCR=<n> | OK |
| AT+FCR=? | (list of supported <n>s) |

Defined values:

| | | |
|-----|---|-------------------------------------------|
| <n> | 0 | The modem will not accept incoming faxes. |
| | 1 | The modem will accept incoming faxes. |

Remarks: none**Source:****Implementation:** complete**1.12.10 AT+FDIS**

This command allows the DTE to parameter the capabilities used for the current session. This command accepts eight numeric parameters (of the T30 standard).

| Command | Possible responses |
|-----------------------------------------------|---------------------------------------------------------------------------|
| AT+FDIS=<vr>, , <wd>, <ln>, <df>, 0, <st> | OK |
| AT+FDIS? | <vr>, , <wd>, <ln>, <df>, 0, <st> |
| AT+FDIS=? | list of supported (<vr>s), (s), (<wd>s), (<ln>s), (<df>s), 0, (<st>s) |

Defined values:

| | |
|------|----------------------|
| <vr> | Vertical Resolution, |
|------|----------------------|

| | |
|---|----------------|
| 0 | Normal: 98 lpi |
|---|----------------|

| | | |
|------|---|----------------------------------|
| | 1 | Fine: 196 lpi |
| | | Bit Rate, |
| | 0 | 2400bps (Modem type: V.27ter) |
| | 1 | 4800bps (Modem type: V.27ter) |
| | 2 | 7200bps (Modem type: V.29) |
| | 3 | 9600bps (Modem type: V.29,V.17) |
| | 4 | 12000bps (Modem type: V.33,V.17) |
| | 6 | 14400bps (Modem type: V.33,V.17) |
| <wd> | | Page Width, |
| | 0 | 1728 pixels in 215mm |
| | 1 | 2048 pixels in 255mm |
| | 2 | 2432 pixels in 303mm. |
| <ln> | | Page Length, |
| | 0 | A4, 297mm |
| | 1 | B4, 364mm |
| | 2 | Unlimited |
| <df> | | Data compression Format, |
| | 0 | 1-D modified huffman |
| | 1 | 2-D modified read |
| | 2 | 2-D uncompressed mode |
| | 3 | 2-D modified modified read |
| <ec> | | Error Correction, |
| | 0 | Disable Fax ECM |
| | 1 | Enable Fax ECM, 64 bytes/frame |
| | 2 | Enable Fax ECM,256 bytes/frame |
| <st> | | Scan time per line, |

| <st> | Description <vr>=0 | Description <vr>=1 |
|------|--------------------|--------------------|
| 0 | 0 ms | 0 ms |
| 1 | 5 ms | 5 ms |
| 2 | 10 ms | 5 ms |
| 3 | 10 ms | 10 ms |
| 4 | 20 ms | 10 ms |
| 5 | 20 ms | 20 ms |
| 6 | 40 ms | 20 ms |
| 7 | 40 ms | 40 ms |

Remarks: none
Source:

Implementation: complete

1.12.11 AT+FDCC

This command allows the DTE to parameter the capabilities used for any sessions. The parameters and default values are the same as these of +FDIS command.

| Command | Possible responses |
|-----------------------------------------------|--------------------------------------------------------------------------|
| AT+FDCC=<vr>, ,<wd>,<ln>,<df>,<ec>,0 ,<st> | OK |
| AT+FDCC=? | <vr>, ,<wd>,<ln>,<df>,<ec>,0 ,<st> |
| AT+FDCC=? | list of supported (<vr>s), (s), (<wd>s), (<ln>s), (<df>s),0 ,(<st>s) |

Remarks: none

Source:

Implementation: complete

1.12.12 AT+FLID

This command allows to define the local ID string. The string has a limited size, and accepts any characters between 32 and 127.

| Command | Possible responses |
|--------------------|--------------------|
| AT+FLID="<string>" | OK |
| AT+FLID=? | (20),(32-127) |

Remarks: none

Source:

Implementation: complete

1.12.13 AT+FPHCTO

This command sets the period the modem waits for another page before it assumes there are no more pages and aborts.

| Command | Possible responses |
|---------------|--------------------------|
| AT+FPHCTO=<n> | OK |
| AT+FPHCTO=? | (list of supported <n>s) |

Defined values:

<n> 0-255sec

Remarks: none

Source:

Implementation: complete

1.12.14 Fax Class 2 indication messages

The following messages are used to indicate DCE Responses.
They are used in communication only.

+FCON:

This response indicates connection with a fax machine.

**+FDGS <vr>,
, <wd>, <ln>, <df>, <ec>, <bf>, <st>:**

This response reports current session capabilities. The parameters are the same than those of AT+FDIS command.

**+FDIS <vr>,
, <wd>, <ln>, <df>, <ec>, <bf>, <st>:**

This response reports remote capabilities. The parameters are the same than those of AT+FDIS command.

+FCFR:

This response indicates confirmation to receive.

+FTSI “<string>”:

This response reports the received transmit station ID string.

+FCSI “<string>”:

This response reports the received called station ID string.

+FPTS <ppr>:

This response reports received page transfer status. The parameter Is the same than one of AT+FPTS command.

+FET <ppm>:

This response reports post page message response. The parameter is the same than the one of AT+FET command.

+FHNG <cause>:

This response reports the hang-up cause. It indicates that the call has been terminated.

| | | |
|---------|-----|-------------------------------------|
| <cause> | 0 | Normal end of connection |
| | 10 | Unspecified transmit phase A error. |
| | 20 | Unspecified transmit phase B error. |
| | 40 | Unspecified transmit phase C error. |
| | 50 | Unspecified transmit phase D error. |
| | 70 | Unspecified receive phase B error. |
| | 90 | Unspecified receive phase C error. |
| | 100 | Unspecified receive phase D error. |

1.13 Functionality commands

1.13.1 A/

Command repeats last given command.

Remarks: No <CR> is needed.
Source: factory default
Implementation: complete

1.13.2 AT+GCAP

Command gives GSM capabilities information.

| Command | Possible responses |
|---------|----------------------|
| +GCAP | +GCAP: +CGSM +FCLASS |

Remarks: none
Source: GSM 07.07/5.6
Implementation: complete

1.13.3 AT+CLCK

Command is used to set and request the status of the modem or network facilities. Special calls could be barred and passwords could be changed.

| Command | Possible responses |
|------------------------------------------|---------------------------------------------------------------------------------------------------------------|
| +CLCK=<fac>,<mode> [,<passwd>[,<class>]] | OK when <mode>=2 +CLCK: <status>[,<class1> [<CR><LF>]+CLCK: <status>, <class2>[...]] |
| +CLCK=? | +CLCK: (list of supported <fac>s) |

Defined values:

| | | |
|-------|------|-----------------------------------------------------------|
| <fac> | "SC" | SIM lock |
| | "AO" | Barr all outgoing calls |
| | "OI" | Barr outgoing international calls |
| | "OX" | Barr outgoing international calls except to home country |
| | "AI" | Barr all incoming calls |
| | "IR" | Barr incoming calls when roaming outside the home country |
| | "AB" | All barring services |
| | "AG" | All outgoing barring services |
| | "AC" | All incoming barring services |

| | | |
|---------|---|--------|
| <mode>: | 0 | Unlock |
| | 1 | Lock |

| | | |
|------------------------|---|----------------------------------------------------------------------------------------------------------------------------------------|
| | 2 | Query status |
| <status>: | 0 | Not active |
| | 1 | Active |
| <passwd>: | | String type; shall be the same as password specified for the facility from the ME user interface or with command Change Password +CPWD |
| <class x> | | Is a sum of integers each representing a class of information (default 7 equals to all classes): |
| | 1 | Voice |
| | 2 | Data |
| | 4 | Fax |
| Remarks: | | none |
| Source: | | GSM 07.07/7.4 |
| Implementation: | | complete |

1.13.4 AT+CPWD

Command is used to set or change passwords for the facility locks of the command AT+CLCK.

| Command | Possible responses | |
|-------------------------------|-----------------------------------------------|-------------------|
| +CPWD=<fac>,<oldpwd>,<newpwd> | OK | +CME ERROR: <err> |
| +CPWD=? | +CPWD: (list of supported <fac>,<pwdlength>s) | +CME ERROR: <err> |

Defined values:

| | |
|------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <fac> | Refer AT+CLCK |
| <oldpwd>, <newpwd>: | String type; <oldpwd> shall be the same as password specified for the facility from the ME user interface or with command Change Password +CPWD and <newpwd> is the new password; maximum length of password can be determined with <pwdlength>. |
| <pwdlength>: | Integer type maximum length of the password for the facility. |
| Remarks: | none |
| Source: | GSM 07.07/7.5 |
| Implementation: | complete |

1.13.5 AT+CFUN

Command is used to set the functionality of the modem. It switches between two power consumption levels.

| Command | Possible responses | |
|-----------------------|--------------------------------------------------------------|-------------------|
| +CFUN=[<fun>[,<rst>]] | OK | +CME ERROR: <err> |
| +CFUN? | +CFUN: <fun> | +CME ERROR: <err> |
| +CFUN=? | +CFUN: (list of supported <fun>s),(list of supported <rst>s) | +CME ERROR: <err> |

Defined values:

| | | |
|--------|---|------------------------------------------------------------|
| <fun>: | 0 | Minimum functionality |
| | 1 | Full functionality |
| <rst>: | 0 | Do not reset the ME before setting it to <fun> power level |
| | 1 | Reset the ME before setting it to <fun> power level |

Remarks: The execution of AT+CFUN=0 is different with the A2D OEM module and the A2D-1 modem.
(See SOFT_ON description for the A2D OEM module or Ignition Line description for the A2D-1 modem.)

AT+CFUN=1,1 is used to reset the GSM software.

Source: GSM 07.07/8.2

Implementation: complete

1.13.6 AT+CPAS

Command is used to request the phone activity status.

| Command | Possible responses | |
|---------|-----------------------------------|-------------------|
| +CPAS | +CPAS: <pas> | +CME ERROR: <err> |
| +CPAS=? | +CPAS: (list of supported <pas>s) | +CME ERROR: <err> |

Defined values:

| | | |
|--------|---|-----------------------------------------------------------------------------------|
| <pas>: | 0 | Ready (ME allows commands from TA/TE) |
| | 1 | Unavailable (ME does not allow commands from TA/TE) |
| | 2 | Unknown (ME is not guaranteed to respond to instructions) |
| | 3 | Ringing (ME is ready for commands from TA/TE, but the ringer is active) |
| | 4 | Call in progress (ME is ready for commands from TA/TE, but a call is in progress) |

5 Asleep (ME is unable to process commands from TA/TE because it is in a low functionality state)

Remarks: none
Source: GSM 07.07/8.1
Implementation: complete

1.13.7 AT+CPOF

Command is used to switch off the module. The modem will perform an IMSI detach procedure before switching off all the internal circuitry. This is highly recommended, because of possible problems at the next registration attempt of a module that was never de-registered.

| Command | Possible responses |
|---------|--------------------|
| +CPOF | OK |

Remarks: The execution of this command is different with the A2D OEM module and the A2D-1 modem. (See SOFT_ON description for the A2D OEM module or Ignition Line description for the A2D-1 modem.)
Source: factory default
Implementation: complete

1.14 Storing/restoring commands

1.14.1 AT&W

Command is used to store modem settings. Stored settings will be available after reset or power off.

| Command | Possible responses |
|---------|--------------------|
| &W | OK |

Remarks: none
Source: GSM 07.07/V.25ter
Implementation: complete

1.14.2 AT&F

Command restores the factory configuration. Restored settings will be available after reset or power off.

| Command | Possible responses |
|---------|--------------------|
| &F | OK |

Remarks: none

Source: GSM 07.07/V.25ter
Implementation: complete

1.14.3 AT+CSAS

Command is used to save special SMS settings.

| Command | Possible responses | |
|---------|--------------------|-------------------|
| +CSAS | OK | +CME ERROR: <err> |
| +CSAS=? | OK | |

Remarks: none
Source: GSM 07.05/3.3.5
Implementation: complete

1.14.4 AT+CRES

Command is used to restore the settings saved by AT+CSAS.

| Command | Possible responses | |
|---------|--------------------|-------------------|
| +CRES | OK | +CME ERROR: <err> |
| +CRES=? | OK | |

Remarks: none
Source: GSM 07.05/3.3.6
Implementation: complete

1.14.5 What is stored where? What are the defaults?

| Command | AT&W (E2P) | AT+CSAS | AT&F (SIM, E2P) | Initial values |
|----------|---------------|---------|--------------------|-------------------------|
| +CMEE | X | | X | 0 |
| +CSCS | X | | X | “PCCP437” |
| ATS0 | X | | X | 0 (no auto-answer) |
| +CICB | X | | X | 2 (speech) |
| +VGR | X | | X | 64 (all speakers) |
| +VGT | X | | X | 64 (all microphones) |
| +SPEAKER | X | | X | 0 (Spk 0 & Mic 0) |
| +SIDET | X | | X | 1,1 |
| +CREG | X | | X | 0 |
| +CMGF | X | | X | 1 (text) |
| +CSDH | X | | X | 0 |
| +CNMI | | X | X | 0, 1, 0, 0, 0 |
| +CSMP | | X | X | 1, 167, 0, 0 |
| +CSCA | | X | | SIM dependant (phase 2) |
| +CCWA | X | | X | 0 |
| +CLIP | X | | X | 0 |
| +COLP | X | | X | 0 |
| +CBST | X | | X | 0, 0, 1 |
| +CRLP | X | | X | 61, 61, 48, 6, 1 |

| | | | | |
|-------------|---------|--|---|----------------------------------------------------------------------------------|
| +CR | X | | X | 0 |
| +CRC | X | | X | 0 |
| +IPR | X | | | 9600 |
| +IFC | X | | | 2,2 |
| +ICF | X | | | 3,4 |
| E | X | | | 1 |
| &C | X | | | 1 |
| &D | X | | | 1 |
| &S | X | | | 1 |
| Q | X | | X | 0 |
| V | X | | X | 1 |
| %C | X | | X | 2 |
| \N | X | | X | 0 |
| +DS | X | | X | 3,0,4096,20 |
| +DR | X | | X | 0 |
| +FDCC,+FIDS | X | | X | 0,5,0,0,2,0,0,0,0 |
| +FCQ | X | | X | 0 |
| +FCR | X | | X | 1 |
| +FPHCTO | X | | X | 30 |
| +FBOR | X | | X | 0 |
| +ECHO | Command | | X | 0,255,1000,5,500,63 (Echo cancel) 0,0,3,10,7,0 (Switch Attenuation) |

1.15 Error message handling and survey

1.15.1 AT +CMEE

Command is used to set the indication of GSM functionality errors.

| | |
|-------------|---------------------------------|
| +CMEE=[<n>] | OK |
| +CMEE? | +CMEE: <n> |
| +CMEE=? | +CMEE: (list of supported <n>s) |

Defined values:

- | | | |
|------|---|-------------------------------------------------------------------|
| <n>: | 0 | Disable +CME ERROR: <err> result code and use ERROR instead |
| | 1 | Enable +CME ERROR: <err> result code and use numeric <err> values |

Remarks: none

Source: GSM 07.07/9.1

Implementation: complete

1.15.2 Mobile equipment error result code : +CME ERROR: <err>

<err> is defined as below :

| | |
|----|-----------------------------------------------------|
| 3 | Operation not allowed |
| 4 | Operation not supported |
| 5 | PH-SIM PIN required (SIM lock) |
| 10 | SIM not inserted |
| 11 | SIM PIN required |
| 12 | SIM PUK required |
| 13 | SIM failure |
| 16 | Incorrect password |
| 17 | SIM PIN2 required |
| 18 | SIMPDK2 required |
| 20 | Memeory full |
| 21 | Invalid index |
| 22 | Not found |
| 24 | Text string too long |
| 26 | Dial string too long |
| 30 | No network service |
| 32 | Network not allowed – emergency calls only |
| 40 | Network personalisation PIN required (Network lock) |

1.15.3 Message service failure result code: +CMS ERROR: <err>

<err> is defined as below :

| | |
|----------|----------------------------------------------------------------------------|
| 1 to 127 | Error cause values from the GSM recommendation 04.11 Annex E-2 (see below) |
| 301 | SMS service of ME reserved |
| 302 | Operation not allowed |
| 303 | Operation not supported |
| 304 | Invalid PDU mode parameter |
| 305 | Invalid text mode parameter |
| 310 | SIM not inserted |
| 311 | SIM PIN required |
| 312 | PH-SIM PIN required |
| 313 | SIM failure |
| 316 | SIM PUK required |
| 317 | SIM PIN2 required |
| 318 | SIM PUK2 required |
| 321 | Invalid memory index |
| 322 | SIM memory full |
| 330 | SC address unknown |

GSM 04.11 Annex E-2: Mobile originating SM-transfer:

Cause no 1: "Unassigned (unallocated) number"

This cause indicates that the destination requested by the Mobile Station cannot be reached because, although the number is in a valid format, it is not currently assigned (allocated).

Cause no 8: "Operator determined barring"

This cause indicates that the MS has tried to send a mobile originating short message when the MS's network operator or service provider has forbidden such transactions.

Cause no 10: "Call barred"

This cause indicates that the outgoing call barred service applies to the short message service for the called destination.

Cause no 21: "Short message transfer rejected"

This cause indicates that the equipment sending this cause does not wish to accept this short message, although it could have accepted the short message since the equipment sending this cause is neither busy nor incompatible.

Cause no 27: "Destination out of service"

This cause indicates that the destination indicated by the Mobile Station cannot be reached because the interface to the destination is not functioning correctly. The term "not functioning correctly" indicates that a signalling message was unable to be delivered to the remote user; e.g., a physical layer or data link layer failure at the remote user, user equipment off-line, etc.

Cause no 28: "Unidentified subscriber"

This cause indicates that the subscriber is not registered in the PLMN (i.e. IMSI not known)

Cause no 29: "Facility rejected"

This cause indicates that the facility requested by the Mobile Station is not supported by the PLMN.

Cause no 30: "Unknown subscriber"

This cause indicates that the subscriber is not registered in the HLR (i.e. IMSI or directory number is not allocated to a subscriber).

Cause no 38: "Network out of order"

This cause indicates that the network is not functioning correctly and that the condition is likely to last a relatively long period of time; e.g., immediately re-attempting the short message transfer is not likely to be successful.

Cause no 41: "Temporary failure"

This cause indicates that the network is not functioning correctly and that the condition is not likely to last a long period of time; e.g., the Mobile Station may wish to try another short message transfer attempt almost immediately.

Cause no 42: "Congestion"

This cause indicates that the short message service cannot be serviced because of high traffic.

Cause no 47: "Resources unavailable, unspecified"

This cause is used to report a resource unavailable event only when no other cause applies.

Cause no 69: "Requested facility not implemented"

This cause indicates that the network is unable to provide the requested short message service.

Cause no 81: "Invalid short message transfer reference value"

This cause indicates that the equipment sending this cause has received a message with a short message reference which is not currently in use on the MS-network interface.

Cause no 95: "Invalid message, unspecified"

This cause is used to report an invalid message event only when no other cause in the invalid message class applies.

Cause no 96: "Invalid mandatory information"

This cause indicates that the equipment sending this cause has received a message where a mandatory information element is missing and/or has a content error (the two cases are indistinguishable).

Cause no 97: "Message type non-existent or not implemented"

This cause indicates that the equipment sending this cause has received a message with a message type it does not recognise either because this is a message not defined or defined but not implemented by the equipment sending this cause.

Cause no 98: "Message not compatible with short message protocol state"

This cause indicates that the equipment sending this cause has received a message such that the procedures do not indicate that this is a permissible message to receive while in the short message transfer state.

Cause no 99: "Information element non-existent or not implemented"

This cause indicates that the equipment sending this cause has received a message which includes information elements not recognised because the information element identifier is not defined or it is defined but not implemented by the equipment sending the cause. However, the information element is not required to be present in the message in order for the equipment sending the cause to process the message.

Cause no 111: "Protocol error, unspecified"

This cause is used to report a protocol error event only when no other cause applies.

Cause no 127: "Interworking, unspecified"

This cause indicates that there has been interworking with a network which does not provide causes for actions it takes; thus, the precise cause for a message which is being send cannot be ascertained.

1.15.4 Specific error result codes +CMS ERROR or +CME ERROR: <err>

<err> is defined as below :

| | |
|-----|-----------------------------------------------------|
| 512 | MM establishment failure (for SMS) |
| 513 | Lower layer failure (for SMS) |
| 514 | CP error (for SMS) |
| 515 | Please wait, init or command processing in progress |
| 516 | USSD error |

1.15.5 AT +CEER

Command is used to show the cause of a failure in the last call-setup or call-modification.

| | |
|---------|-----------------|
| +CMER | +CEER: <report> |
| +CMEE=? | OK |

Defined values:

<report>: cause as written below (imformation element as stated in GSM recommendation 04.08)

| Cause value | Diagnostic |
|-------------|-------------------------------------------|
| 1 | Unassigned (unallocated) number |
| 3 | No route to destination |
| 6 | Channel unacceptable |
| 8 | Operator determined barring |
| 16 | Normal call clearing |
| 17 | User busy |
| 18 | No user responding |
| 19 | User alerting, no answer |
| 21 | Call rejected |
| 22 | Number changed |
| 26 | Non selected user clearing |
| 27 | Destination out of order |
| 28 | Invalid number format (incomplete number) |
| 29 | Facility rejected |
| 30 | Response to STATUS ENQUIRY |
| 31 | Normal, unspecified |
| 34 | No circuit/channel available |
| 38 | Network out of order |
| 41 | Temporary failure |

| | |
|-----|--------------------------------------------------------------------|
| 42 | Switching equipment congestion |
| 43 | Access information discarded |
| 44 | requested circuit/channel not available |
| 47 | Resources unavailable, unspecified |
| 49 | Quality of service unavailable |
| 50 | Requested facility not subscribed |
| 55 | Incoming calls barred with in the CUG |
| 57 | Bearer capability not authorized |
| 58 | Bearer capability not presently available |
| 63 | Service or option not available, unspecified |
| 65 | Bearer service not implemented |
| 68 | ACM equal to or greater than ACMmax |
| 69 | Requested facility not implemented |
| 70 | Only restricted digital information bearer capability is available |
| 79 | Service or option not implemented, unspecified |
| 81 | Invalid transaction identifier value |
| 87 | User not member of CUG |
| 88 | Incompatible destination |
| 91 | Invalid transit network selection |
| 95 | Semantically incorrect message |
| 96 | Invalid mandatory information |
| 97 | Message type non-existent or not implemented |
| 98 | Message type not compatible with protocol state |
| 99 | Information element non-existent or not implemented |
| 100 | Conditional IE error |
| 101 | Message not compatible with protocol state |
| 102 | Recovery on timer expire |
| 111 | Protocol error, unspecified |
| 127 | Interworking, unspecified |

All other values in the range 0 to 31 shall be treated as cause 31.

All other values in the range 32 to 47 shall be treated as cause 47.

All other values in the range 48 to 63 shall be treated as cause 63.

All other values in the range 64 to 79 shall be treated as cause 79.

All other values in the range 80 to 95 shall be treated as cause 95.

All other values in the range 96 to 111 shall be treated as cause 111.

All other values in the range 112 to 127 shall be treated as cause 127.

| | |
|-----|----------------------------------------|
| 240 | FDN is active and number is not in FDN |
| 241 | Call operation not allowed |
| 252 | Call barring on outgoing calls |
| 253 | Call barring on incoming calls |
| 254 | Call impossible |
| 255 | Lower layer failure |

Remarks: none

Source: GSM 07.07/6.10

Implementation: complete

2 A2D-A / A2D-B

2.1 Technical data

GSM capability:

E-GSM and DCS (GSM ETSI Phase I and II)

GSM data services:

300 ... 14400 BPS, asynchronous, transparent and non-transparent
(V.21, V.22, V.23, V.22bis, V.26ter, V.32, V.34, V.110)

Dimensions (L x W x H in mm):

| | |
|--------------------|-----------------------------------------------------|
| 83,0 x 50,5 x 10,5 | for the A2D-A (module with mounting brackets) |
| 72,0 x 50,5 x 10,5 | for the A2D-B (module without mounting brackets) |

Weight (in g):

| | |
|----|-----------------------------------------------------|
| 54 | for the A2D-A (module with mounting brackets) |
| 52 | for the A2D-B (module without mounting brackets) |

Temperature range (in °C):

Operation

-20... +55

Transportation

-40... +70

Storage

-25... +70

RF characteristics:

Receiver

| | | |
|-----------------------|---|-----------|
| EGSM Sensitivity | : | <-104dBm |
| DCS Sensitivity | : | < -100dBm |
| Selectivity @ 200 kHz | : | > +9dBc |
| Selectivity @ 400 kHz | : | > +41dBc |
| Dynamic range | : | 62 dB |
| Intermodulation | : | > -43dBm |
| Co-channel rejection | : | >= 9dBc |

Transmitter

| | | |
|-----------------------------|---|----------------|
| Maximum output power (EGSM) | : | 33dBm +/- 2dB |
| Maximum output power (DCS) | : | 30dBm +/- 2dB |
| Minimum output power (EGSM) | : | 5dBm +/- 5dB |
| Minimum output power (DCS) | : | 0dBm +/- 5dB |
| H2 level | : | < -30dBm |
| H3 level | : | < -30dBm |
| Noise in 925 - 935 MHz | : | < -67dBm |
| Noise in 935 - 960 MHz | : | < -79dBm |
| Noise in 1805 - 1880 MHz | : | < -71dBm |
| Phase error at peak power | : | < 5 ° RMS |
| Frequency error | : | +/- 0.1ppm max |

Supply voltage (in V):

| | |
|------------|--------------------------|
| 4.0 to 7.0 | absolute maximum ratings |
|------------|--------------------------|

Average current (in mA at 5V nominal):

| | |
|-------|--------------------------------------------------------------------------------------------------------|
| 0,015 | in OFF mode 2 (EN pulled to LOW, the internal regulator is switched off) |
| 17* | in OFF mode 1 (AT+CPOF was issued and SOFT_ON was set to LOW, the internal regulator is still working) |
| 30* | in idle mode (base station sends at -85 dBm) |
| 260* | in transmit mode at power level 7 |
| 350* | in transmit mode at power level 5 (Maximum) |

* Serial interface is applied and working.

SIM card Reader:

Internal, for small SIM cards (5/3V)

RS 232:

| | |
|-------------|------------------------------------------------------------|
| +/-12V | RxD, TxD only |
| 2.8V | RX, TX, RTS, CTS, DTR, DSR, DCD, RI |
| 300..115200 | Baud rates for serial link (2400..19200 with auto-bauding) |

2.2 Possible external devices:**Audio:**

| | |
|------------------|----------------------------|
| 2KΩ differential | Microphone 1 impedance |
| 2V | Microphone 1 bias voltage |
| 0,5mA | Microphone 1 input current |
| 2KΩ differential | Microphone 2 impedance |
| 2V | Microphone 2 bias voltage |
| 0,5mA | Microphone 2 input current |
| >50Ω (<1nF) | Speaker 1 impedance |
| >50Ω (<1nF) | Speaker 2 impedance |

Ringer:


80mA max. current

SIM card reader:

External, 10 .. 15cm maximum cable length

2.3 Connectors at the A2D

In the following pictures the connectors of the A2D module are to be seen.

**C1 :**

40-pin connector SMD Type: FH (AMP-Part No.:0-177984-1)
→ Counterpart for application 0-177983-1

C3 :


6 pin connector; 2,54mm double row
0,45mm pin diameter
(CAB –Part No.:712-97-103)
→ Counterpart for application 1102-171-006

C4 :

4 pin connector; 2,45mm single row
0,45mm pin diameter
(CAB-Part-No.:315-97-104-41-003)
→ Counterpart for application 1101-191-004

C5:

RF-connector Type: MC-Card (RADIALL-Part No.: 199005801)
→ Counterpart for application 199005250

**C2 :**

15 pin connector Type: PCCC (AMP-Part No.:5-558556-1)
 → Counterpart for application 5-558556-1,
 0-558666-1,0-558665-1 and 0-558709-2

2.4 Pin-out of the A2D module

The following table shows the 40-pin connector that has changed from the original A2 single band module.

In the red marked fields there are “new” signals shown, that are not pin-compatible with the A2 single band module.

In these tables CMOS means 2.8V. You may use a 3V or 3.3V CMOS level logic (never 5V) on the 2.8V I/O's. However, it is required to add serial resistance on all the lines you will use (typical value: from 4.7 to 10 KΩ).

As long as the 3V_SIM signal is left untouched the SIM signals on C3 and C1 are compatible to 3V and 5V (except SIMPRES on C1, which is CMOS). Otherwise they are 3V only.

| C1 | | 40-pin | | |
|----|---------|--------|---------------------|------------------------------------------|
| 1 | SIMRST | Input | 3V or 3/5V | SIM Reset |
| 2 | SIMCLK | Output | 3V or 3/5V | SIM Clock |
| 3 | SIMDATA | In/Out | 3V or 3/5V | SIM Data |
| 4 | SIMVCC | In/Out | 3V or 3/5V | SIM Card power supply |
| 5 | SIMCARD | In/Out | 3V or 3/5V | SIM Card programming power supply |
| 6 | GND | | Power ground | Battery power ground |
| 7 | GND | | Power ground | Battery power ground |
| 8 | GND | | Power ground | Battery power ground |
| 9 | GND | | Power ground | Battery power ground |
| 10 | GND | | Power ground | Battery power ground |
| 11 | GPI | Input | CMOS | General purpose Input |
| 12 | EN | Input | CMOS | Internal power enable (HIGH=enable) |
| 13 | GPIO 1 | In/Out | CMOS | General purpose Input/Output (Flash LED) |
| 14 | VBAT | | Power supply | Battery power supply |
| 15 | VBAT | | Power supply | Battery power supply |
| 16 | VBAT | | Power supply | Battery power supply |
| 17 | VBAT | | Power supply | Battery power supply |
| 18 | VBAT | | Power supply | Battery power supply |
| 19 | SIMPRES | Input | CMOS | SIM present (SIM card detection) |
| 20 | BRSF | Input | CMOS | Flash update – not used anymore |
| 21 | GPIO 0 | In/Out | CMOS | General purpose Input/Output |
| 22 | GPO 1 | Output | CMOS | General purpose Output |
| 23 | GPIO 4 | In/Out | CMOS | General purpose Input/Output |
| 24 | VCCRTC | In/Out | SUPPLY | RTC back-up battery supply (not used) |
| 25 | 3V SIM | Input | SUPPLY | SIM power supply (HIGH = 3V only SIM) |
| 26 | RSTF | Input | SCHMITT | Reset - Active Low (see next chapter) |
| 27 | TX | Output | CMOS | RS-232 Transmit Data |
| 28 | RX | Input | CMOS | RS-232 Receive Data |
| 29 | SOFT_ON | Input | CMOS | Turn phone on (see next chapter) |
| 30 | RING | Output | CMOS | Ringer Interface |
| 31 | RI | Output | CMOS | RS-232 Ring Indicator |
| 32 | DCD | Output | CMOS | RS-232 Data Carrier Detect |
| 33 | DSR | Output | CMOS | RS-232 Data Set Ready |
| 34 | RTS | Input | CMOS | RS-232 Ready To Send |
| 35 | DTR | Input | CMOS | RS-232 Data Terminal Ready |
| 36 | CTS | Output | CMOS | RS-232 Clear To Send |
| 37 | SPKR1_P | | Differential Output | Speaker 1 positive |
| 38 | SPKR1_N | | Differential Output | Speaker 1 negative |
| 39 | MIC1_P | | Differential Input | Microphone 1 positive |
| 40 | MIC1_N | | Differential Input | Microphone 1 negative |

A short description of the use of the non-common signals can be found in the next chapter.

All unused signals can be left open.

| C2 | | 15-pin | | |
|----|---------|---------------------|------|----------------------------------------|
| 1 | TxD | Output | V.24 | RS-232 Transmit Data |
| 2 | RxD | Input | V.24 | RS-232 Receive Data |
| 3 | SOFT_ON | Input | CMOS | Turn phone on (see next chapter) |
| 4 | RING | Output | CMOS | Ringer Interface |
| 5 | BRSF | Input | CMOS | Flash update – not used anymore |
| 6 | SPKR2_P | Differential Output | | Speaker 2 positive |
| 7 | SPKR2_N | Differential Output | | Speaker 2 negative |
| 8 | MIC2_P | Differential Input | | Microphone 2 positive |
| 9 | MIC2_N | Differential Input | | Microphone 2 negative |
| 10 | V_EXT | Power | | Connected to VEXT of C4* |
| 11 | V_EXT | Power | | Connected to VEXT of C4* |
| 12 | V_EXT | Power | | Connected to VEXT of C4* |
| 13 | GND | Power | | Ground |
| 14 | GND | Power | | Ground |
| 15 | GND | Power | | Ground |

| C3 | | 6-pin | | |
|----|---------|--------|------------|------------------|
| 1 | SIMRST | Input | 3V or 3/5V | SIM Reset |
| 2 | SIMGND | In/Out | 3V or 3/5V | SIM Power ground |
| 3 | SIMCLK | Output | 3V or 3/5V | SIM Clock |
| 4 | SIMVCC | In/Out | 3V or 3/5V | SIM Power supply |
| 5 | SIMDATA | In/Out | 3V or 3/5V | SIM data |
| 6 | SIMVCC | In/Out | 3V or 3/5V | SIM Power supply |

| C4 | | 4-pin | |
|----|------|-------------------|--------------------------|
| 1 | VEXT | Ext. Power supply | Connected to VEXT of C2* |
| 2 | VBAT | Power supply | Battery power supply |
| 3 | GND | Power ground | Battery power ground |
| 4 | GND | Power ground | Battery power ground |

* For supplying power over the VEXT pin of C2 a connection has to be made from pin 1 to pin 2 of C4. VEXT is a connection from C2 to C4 only, it does not touch any signal or power plane inside the A2D!

2.5 Special functionality pins

There are a few pins needed for the operation of the module. The handling of that pins is described as follows.

2.5.1 Pin 12 on C1 (EN)

This signal is an input of the internal voltage regulator.


- Pull to LOW to switch the voltage regulator off (for minimum current consumption).
- Pull to HIGH or leave the signal open if EN is not used.

2.5.2 Pin 13 on C1 (GPIO 1 → Flash LED)

This signal can be used to show the current status of the module:

- If GPIO 1 is LOW then the module is off.
- If it is continuously HIGH then module is on, but not registered into a network.
- If GPIO 1 is flashing in a 2sec period then the module is on and registered into a network.
- If it flashes in a 1sec period then the module is on and a call is in progress (incoming or outgoing).


GPIO 1 can be an input into a controller (here it needs to be driven by an open collector circuit) or used together with a LED (see picture below):



2.5.3 Pin 19 on C1 (SIMPRES)

This signal needs to be driven by an open collector circuit. It is used by the modules firmware to detect a SIM card exchange when the module is online. A low to high transition means SIM card is inserted and the module will be able to accept the AT+CPIN command. A high to low transition means SIM card has been removed, the module will de-register from the network and show the unsolicited error code CME ERROR: 10.

If 3V logic level is used the signal could be driven directly (2.8V CMOS!, see chapter before for handling hints). If 5V logic level is used the figure below shows an example for the circuitry needed.



2.5.4 Pin 25 on C1 (3V SIM)

This signal needs to be driven by an external open collector circuit.

- Pull this signal to HIGH to work with a **3V only (!)** SIM. The SIM power supply will switch to 3V SIMVCC.
- Pull to LOW or leave signal open to use 5V or 5/3V SIM. SIMVCC will be 5V for the use of normal 5V or 5/3V-tolerant SIM cards.

2.5.5 Pin 26 on C1 (RSTF)

This signal needs to be driven by an external open collector circuit.

- To issue a hardware reset pull the signal to LOW for a minimum of 100ms.
- Pull the signal to HIGH or leave it open for normal operation.

2.5.6 Pin 29 on C1, Pin 3 on C2 (SOFT ON)

This signal needs to be driven by an external open collector circuit.

- For switching the module on (external power must be connected!) set the SOFT_ON signal to HIGH for approx. 3 sec. The signal could be left HIGH until module shall be switched off.
- For switching the module off the commands AT+CPOF or AT+CFUN=0 have to be issued.
 - If SOFT_ON is HIGH then only the RF part of the module is off, but the AT command set is still working (AT+CFUN=1 can be used to wake up the RF part again) → the Flash_LED stays HIGH.
 - If SOFT_ON is LOW then the complete GSM engine goes OFF → the Flash_LED goes LOW. Some small power consumption will be still there, use the EN pin to avoid that.

It is not recommended to switch the module on and off via the power supply (e.g. by tying the SOFT_ON constantly to HIGH). The module will then have no possibility to de-register correctly from the network and this will cause problems at the next attempt to register.

2.6 Firmware Download Procedure

The download procedure will be documented with the firmware release on the FALCOM Homepage (www.falcom.de).

2.7 Resetting the A2D OEM module via AT+CFUN=1,1

If the GSM software is still running, while the user feels the need to reset the module, AT+CFUN=1,1 could be used. This will de-register the modem from the network and bring it into the state before the PIN could be entered. The Flash_LED pin will shortly toggle to OFF and back to ON again to show the progress.

3 A2D-1 Modem (first version)

3.1 Remarks

The first version of the A2D-1 modem was sold until September 2000. It can be recognised by looking at the label at the backside of the modem. Holding the modem with the 9-pin serial interface B pointing to the left, the label can be read from left to right. The Reset button hole is located above the label at the edge of the modem. For a view please see pictures later in this chapter.

3.2 Technical Data

Dimensions: 115mm x 54mm x 33mm (B x H x L)

Weight: 160g

Power Supply:
 10,8...31,2 V DC
 235mA (max.) 12V EGSM*
 190mA (max.) 12V DCS*
 48mA (idle) 12V*

**IF MODEM IS SWITCHED OFF (BY AT+CPOF OR AT+CFUN=0),
 BUT POWER IS STILL SUPPLIED:**


25mA (off) 12V*

* Serial interface is applied and working.

Temperature Range: Storage: -20°C to +70°C
 Use: -20°C to +55°C


Interface A: Power supply, Cable Reference

| | | |
|-------|--------|---------------|
| pin 4 | brown | 10,8 .. 31,2V |
| pin 3 | green | Ignition |
| pin 2 | yellow | |
| pin 1 | white | Gnd |
| LED | green | Reset |
| LED | yellow | Power |




Interface B: RS232 / V24 9 pin D-Sub to DIN 41652

| | |
|-------|--------------------------------|
| pin 1 | DCD |
| pin 2 | TXD |
| pin 3 | RXD |
| pin 4 | DTR |
| pin 5 | GND |
| pin 6 | DSR |
| pin 7 | RTS |
| pin 8 | CTS |
| pin 9 | RI (optional 10,8 .. 31,2V/5V) |



Interface C: RJ 45 8 pin shielded for Audio, RS232 and power supply for further devices.

| | |
|-------|-------------------------------|
| pin 1 | 10,8 .. 31,2V (optional 5V) |
| pin 2 | TXD |
| pin 3 | RXD |
| pin 4 | GND |
| pin 5 | SPK + |
| pin 6 | SPK - |
| pin 7 | MIC + |
| pin 8 | MIC - |





Interface D: Antenna 50Ω FME female

SIM-Card interface: for small SIM-Cards 3V and 5V

Audio interface: Electret-Microphone
Loudspeaker >50Ω
Ground

3.3 Connectors at the A2D-1





3.4 Functional description

The GSM modem FALCOM A2D-1 is a mobile station for the transmission of voice, data and fax calls as well as SMS in GSM networks.

The GSM modem FALCOM A2D-1 consists of the following components:

- GSM transceiver
- Power supply unit
- Serial link (V.24) for data transmission and control

If the GSM modem FALCOM A2D-1 is registered in the network, it acts just like a regular fax/data modem. To control the GSM modem there is an advanced set of AT-commands according to GSM ETSI 07.07 and 07.05 implemented. The two LED's on the Interface A are showing the state of the FALCOM A2D-1. The yellow LED signals power connection and the green LED signals a "RESET" function, "SOFT_ON" procedure.

3.4.1 Ignition line

The Ignition Line on Interface A uses an internal processor to control the timing of the "SOFT_ON" procedure of the internal A2D GSM modem (refer to the A2D section of this manual).

To switch the modem on the Ignition Line has to be toggled from Ground to a high voltage level (10,8V-31,2V). The green LED on interface C shows the progress of the "SOFT_ON" procedure. After the green LED goes out the procedure is ready (this takes approx. 5sec).

To switch the modem off the commands AT+CPOF or AT+CFUN=0 (see AT commands section) has to be issued. To switch the modem on again see above. **The modem could never be switched off by pulling the Ignition Line to ground !!!**

3.4.2 Serial handling

The GSM modem FALCOM A2D-1 allows control of the GSM modem over the interface B or interface C. The interface B is a implementation of a serial interface corresponding EIA-RS232-C. See table for details:

| CCITT V24 | Pin | Description | Direction |
|-----------|-----|---------------------------|-----------|
| 102 | 5 | Signal Ground (GND) | |
| 103 | 3 | Transmitted Data (TxD) | IN |
| 104 | 2 | Received Data (RxD) | OUT |
| 105 | 7 | Request To Send (RTS) | IN |
| 106 | 8 | Clear To Send (CTS) | OUT |
| 107 | 6 | Data Set Ready (DSR) | OUT |
| 108 | 4 | Data Terminal Ready (DTR) | IN |
| 109 | 1 | Data Carrier Detect (DCD) | OUT |
| 125 | 9 | Ring Indicator (RI) | OUT |

Both interface B and C are not independent usable. The interface B has the highest priority. If you don't want to use the interface B you must deactivate the signals RTS and DTR (or remove connection). With the interface C you have the audio and control functionality on one interface.

See table for connections:

| Pin | Description | Direction |
|-----|----------------------------------------|-----------|
| 1 | Power Supply (input voltage/option 5V) | OUT |
| 2 | Transmitted Data (TxD) | IN |
| 3 | Received Data (RxD) | OUT |
| 4 | Ground | |
| 5 | SPK+ | |
| 6 | SPK- | |
| 7 | MIC+ | |
| 8 | MIC- | |

3.4.3 Reset configuration

In case of malfunction the GSM modem FALCOM A2D-1 offers various RESET possibilities.

If the GSM modem is currently running the green LED on interface C shows the RESET procedure. For a RESET of the GSM modem please use the following ways:

- “RESET” switch at the backside of the GSM modem.
- Ignition removed and supplied again to high voltage level (10,8V-31,2V).
- “Break” on serial interfaces B or C (Transmit Data [TxD] set to “LOW” for >100ms).

If the GSM software is still running, while the user feels the need to reset the modem, AT+CFUN=1,1 could be used. This will de-register the modem from the network and bring it into the state before the PIN could be entered.

3.4.4 Firmware update

The download procedure will be documented with the firmware release on the FALCOM Homepage (www.falcom.de).

4 A2D-1 Modem (second version)

4.1 Remarks

The second version of the A2D-1 modem we have sold since September 2000. It can be recognised by looking at the label at the backside of the modem. Holding the modem with Interface B pointing downward, the label can be read from left to right. The Reset button hole is located above the label in the upper middle of the backside of the modem. For a view please see pictures later in this chapter.

4.2 Technical Data

Dimensions: 115mm x 54mm x 33mm (B x H x L)

Weight: 160g

Power Supply:
 10,8...31,2 V DC
 235mA (max.) 12V EGSM*
 190mA (max.) 12V DCS*
 48mA (idle) 12V*

**IF MODEM IS SWITCHED OFF (BY AT+CPOF OR AT+CFUN=0),
 BUT POWER IS STILL SUPPLIED:**


25mA (off) 12V*

* Serial interface is applied and working.

Temperature Range: Storage: -20°C to +70°C
 Use: -20°C to +55°C


Interface A: Power supply, Cable Reference

| | | |
|-------|--------|---------------|
| pin 4 | brown | 10,8 .. 31,2V |
| pin 3 | green | Ignition |
| pin 2 | yellow | |
| pin 1 | white | Gnd |
| LED | green | SIM ACC |
| LED | yellow | Power |




Interface B: RS232 / V24 9 pin D-Sub to DIN 41652

| | |
|-------|--------------------------------|
| pin 1 | DCD |
| pin 2 | TXD |
| pin 3 | RXD |
| pin 4 | DTR |
| pin 5 | GND |
| pin 6 | DSR |
| pin 7 | RTS |
| pin 8 | CTS |
| pin 9 | RI (optional 10,8 .. 31,2V/5V) |



Interface C: RJ 45 8 pin shielded for Audio, RS232 and power supply for further devices.

| | |
|-------|-------------------------------|
| pin 1 | 10,8 .. 31,2V (optional 5V) |
| pin 2 | TXD |
| pin 3 | RXD |
| pin 4 | GND |
| pin 5 | SPK + |
| pin 6 | SPK - |
| pin 7 | MIC + |
| pin 8 | MIC - |





Interface D: Antenna 50Ω FME female

SIM-Card interface: for small SIM-Cards 3V and 5V

Audio interface: Electret-Microphone
Loudspeaker >50Ω
Ground

4.3 Connectors at the A2D-1





4.4 Functional description

The GSM modem FALCOM A2D-1 is a mobile station for the transmission of voice, data and fax calls as well as SMS in GSM networks.

The GSM modem FALCOM A2D-1 consists of the following components:

- GSM transceiver
- Power supply unit
- Serial link (V.24) for data transmission and control

If the GSM modem FALCOM A2D-1 is registered in the network, it acts just like a regular fax/data modem. To control the GSM modem there is an advanced set of AT-commands according to GSM ETSI 07.07 and 07.05 implemented. The two LED's on the Interface A are showing the state of the FALCOM A2D-1. The yellow LED signals power connection and the green LED signals that the SIM is read and accepted.

4.4.1 Ignition line

The Ignition Line on Interface A uses an internal processor to control the timing of the “SOFT_ON“ procedure of the internal A2D GSM modem (refer to the A2D section of this manual).

To switch the modem on the Ignition Line has to be toggled from Ground to a high voltage level (10,8V-31,2V). The green LED on interface C shows the progress of the “SOFT_ON“ procedure. After the green LED goes on the procedure is ready (this takes approx. 5sec).

To switch the modem off the commands AT+CPOF or AT+CFUN=0 (see AT commands section) has to be issued. To switch the modem on again see above. **The modem could never be switched off by pulling the Ignition Line to ground !!!**

4.4.2 Serial handling

The GSM modem FALCOM A2D-1 allows control of the GSM modem over the interface B or interface C. The interface B is a implementation of a serial interface corresponding EIA-RS232-C. See table for details:

| CCITT V24 | Pin | Description | Direction |
|-----------|-----|---------------------------|-----------|
| 102 | 5 | Signal Ground (GND) | |
| 103 | 3 | Transmitted Data (TxD) | IN |
| 104 | 2 | Received Data (RxD) | OUT |
| 105 | 7 | Request To Send (RTS) | IN |
| 106 | 8 | Clear To Send (CTS) | OUT |
| 107 | 6 | Data Set Ready (DSR) | OUT |
| 108 | 4 | Data Terminal Ready (DTR) | IN |
| 109 | 1 | Data Carrier Detect (DCD) | OUT |
| 125 | 9 | Ring Indicator (RI) | OUT |

Both interface B and C are not independent usable. The interface B has the highest priority. If you don't want to use the interface B you must deactivate the signals RTS and DTR (or remove connection). With the interface C you have the audio and control functionality on one interface.

See table for connections:

| Pin | Description | Direction |
|-----|----------------------------------------|-----------|
| 1 | Power Supply (input voltage/option 5V) | OUT |
| 2 | Transmitted Data (TxD) | IN |
| 3 | Received Data (RxD) | OUT |
| 4 | Ground | |
| 5 | SPK+ | |
| 6 | SPK- | |
| 7 | MIC+ | |
| 8 | MIC- | |

4.4.3 Reset configuration

In case of malfunction the GSM modem FALCOM A2D-1 offers various RESET possibilities.

If the GSM modem is currently running the green LED on interface C shows the RESET procedure. For a RESET of the GSM modem please use the following ways:

- “RESET” switch at the backside of the GSM modem.
- Ignition removed and supplied again to high voltage level (10,8V-31,2V).
- “Break” on serial interfaces B or C (Transmit Data [TxD] set to “LOW” for >100ms).

If the GSM software is still running, while the user feels the need to reset the modem, AT+CFUN=1,1 could be used. This will de-register the modem from the network and bring it into the state before the PIN could be entered.

4.4.4 SIM ACC LED

The SIM ACC LED show the acceptation of the SIM card by the modem. After the modem is switched on, the LED lights permanently, until the PIN is entered successfully. In case of having the PIN disabled, this will happen automatically. After the acceptation the LED will flash in a 2sec interval. If an incoming or outgoing call is in progress, the LED will flash in a 1sec interval.

4.4.5 Firmware update

The download procedure will be documented with the firmware release on the FALCOM Homepage (www.falcom.de).

5 Appendix

5.1 Recommendations for power supply layout (A2D-A/B/C)

The FALCOM A2D is specified for a power supply voltage in the range of 4 to 7 VDC. It is recommended to design the power supply so that even current bursts of up to 3A (for 577µs, rise time 10µs, period 4.615ms, caused by GSM-typical radio transmission) do not cause ripple voltages higher than 100 ... 150mV.

If the power supply is using input-voltages of more than 50Vrms or 75 VDC it is the responsibility of the applicant to conform with the safety requirements of Telecommunication Terminal Equipment (such as 73/23/EEC).


5.2 Recommendations for power supply (A2D-1)

It is recommended to use the FALCOM A2 PS002 power supply. Also any other power supply in the range of 10.7 ... 31 VDC can be used. It should be able to deliver 2A peak current (for 577µs, rise time 10µs, period 4.615ms, caused by GSM-typical radio transmission), where the ripple voltage of the power supply is recommended to be lower than 300mV.

If the power supply is using input-voltages of more than 50Vrms or 75 VDC it is the responsibility of the applicant to conform with the safety requirements of Telecommunication Terminal Equipment (such as 73/23/EEC).



5.3 SIM-card reader from AMP

An example of an external SIM-card reader to be connected to the A2D-A/B/C is shown in the following schematics:



5.4 Device holder for A2D-1

Halterung Falcom A1/A2



5.5 Mounting clamps for A2D-A/B/C

