


GM862 Family Hardware User Guide
1vv0300794 Rev. 0 – 03/12/2008

This document is relating to the following products:



GM862-QUAD	3 990 250 659
GM862-QUAD	GM862QUD****
GM862-QUAD-PY	3 990 250 658
GM862-QUAD-PY	GM862PYT****

The suffix "****" depends on the module HW/SW configuration. Please contact your Telit representative for details.



GM862-GPS	3 990 250 689
GM862-GPS	GM862GPS****

The suffix "****" depends on the module HW/SW configuration. Please contact your Telit representative for details.

This document substitutes the following specifications:

- 1vv0300728 GM862-GPS Hardware User Guide
- 1vv0300748 GM862-QUAD/QUAD-PY Hardware User Guide



Disclaimer

The information contained in this document is the proprietary information of Telit Communications S.p.A. and its affiliates (“TELIT”).

The contents are confidential and any disclosure to persons other than the officers, employees, agents or subcontractors of the owner or licensee of this document, without the prior written consent of Telit, is strictly prohibited.

Telit makes every effort to ensure the quality of the information it makes available. Notwithstanding the foregoing, Telit does not make any warranty as to the information contained herein, and does not accept any liability for any injury, loss or damage of any kind incurred by use of or reliance upon the information.

Telit disclaims any and all responsibility for the application of the devices characterized in this document, and notes that the application of the device must comply with the safety standards of the applicable country, and where applicable, with the relevant wiring rules.

Telit reserves the right to make modifications, additions and deletions to this document due to typographical errors, inaccurate information, or improvements to programs and/or equipment at any time and without notice.

Such changes will, nevertheless be incorporated into new editions of this document.

All rights reserved.

© 2008 Telit Communications S.p.A.



Contents

3.1.	DESCRIPTION	8
3.2.	CONNECTORS POSITION	8
3.3.	BOARD TO BOARD CONNECTOR.....	9
3.4.	MOLEX 52991-0508 (MALE) GM862 CONNECTOR PIN-OUT.....	9
3.5.	ANTENNA CONNECTORS	11
4.1.	GSM ANTENNA REQUIREMENTS	13
4.2.	GSM ANTENNA - INSTALLATION GUIDELINES.....	13
4.3.	GPS ANTENNA REQUIREMENTS (ONLY FOR GM862-GPS).....	14
4.4.	GPS ANTENNA - INSTALLATION GUIDELINES	14
5.1.	RESET SIGNAL	15
6.1.	TURNING ON THE GM862	17
6.2.	TURNING OFF THE GM862.....	19
6.2.1.	<i>Hardware Shutdown</i>	19
6.2.2.	<i>Hardware Unconditional Shutdown</i>	19
6.2.3.	<i>Hardware Unconditional Restart</i>	21
7.1.	POWER SUPPLY REQUIREMENTS	23
7.2.	GENERAL DESIGN RULES.....	25
7.2.1.	<i>Electrical Design Guidelines</i>	25
7.2.2.	<i>Thermal Design Guidelines</i>	30
7.2.3.	<i>Power Supply PCB Layout Guidelines</i>	31
7.2.4.	<i>Parameters for ATEX Application</i>	32
8.1.	GM862-GPS SERIAL PORTS.....	34
8.2.	GM862-QUAD/ QUAD-PY SERIAL PORTS	34
8.3.	MODEM SERIAL PORT	34
8.4.	GPS SERIAL PORT (GM862-GPS ONLY).....	36
8.5.	TRACE SERIAL PORT (GM862-QUAD-PY ONLY)	36
8.6.	LEVEL TRANSLATION	36
8.7.	5V UART LEVEL TRANSLATION	38
9.1.	INPUT LINES (MICROPHONE).....	41
9.1.1.	<i>Short description</i>	41
9.1.2.	<i>Input Lines Characteristics</i>	42
9.2.	OUTPUT LINES (SPEAKER).....	43
9.2.1.	<i>Short Description</i>	43
9.2.2.	<i>Output Lines Characteristics</i>	44
10.1.	GPIO LOGIC LEVELS	46
10.2.	USING A GPIO PIN AS INPUT	47
10.3.	USING A GPIO PIN AS OUTPUT	47
10.4.	USING THE RF TRANSMISSION CONTROL GPIO4.....	47
10.5.	USING THE RFTXMON OUTPUT GPIO5	47
10.6.	USING THE ALARM OUTPUT GPIO6.....	48
10.7.	USING THE BUZZER OUTPUT GPIO7.....	48
11.1.	ADC CONVERTER.....	50
11.1.1.	<i>Description</i>	50
11.1.2.	<i>Using ADC Converter</i>	50
13.1.	ANTENNA COAXIAL CABLE FIXING	52
13.2.	PRECAUTIONS	53




2. Dimensions

The Telit GM862 module overall dimension are:


- Length: 43.9 mm
- Width: 43.9 mm
- Thickness: 6.9 mm
- Volume: $\cong 13 \text{ cm}^3$

The layout of the GM862-GPS module is shown in the following figure:






GM862 Family Hardware User Guide
1vv0300794 Rev. 0 – 03/12/2008

The layout of the GM862-QUAD/ QUAD-PY modules is shown in the following figure:




3.3. Board to Board Connector

Molex 52991-0508 (male) GM862 Connector LAY-OUT



PCB LAYOUT: COMPONENT SIDE



3.4. Molex 52991-0508 (male) GM862 Connector PIN-OUT

Pin	Signal	I/O	Function	Internal Pull up	Type
1	VBATT	-	Main power supply		Power
2	GND	-	Ground		Power
3	VBATT	-	Main power supply		Power
4	GND	-	Ground		Power
5	VBATT	-	Main power supply		Power
6	A/D	-	A/D converter @ 11 bit (Input Impedance >100Kohm)		Max 2V input



GM862 Family Hardware User Guide

1vv0300794 Rev. 0 – 03/12/2008

Pin	Signal	I/O	Function	Internal Pull up	Type
7	VBATT	-	Main power supply		Power
8	CHARGE	AI	Battery Charger Input		Power
9	EAR_HF+	AO	Handsfree ear output, phase +		Audio
10	EAR_MT-	AO	Handset earphone signal output, phase -		Audio
11	EAR_HF-	AO	Handsfree ear output, phase -		Audio
12	EAR_MT+	AO	Handset earphone signal output, phase +		Audio
13	MIC_HF-	AI	Handsfree microphone input; phase -		Audio
14	MIC_MT+	AI	Handset microphone signal input; phase+		Audio
15	MIC_HF+	AI	Handsfree microphone input; phase +		Audio
16	MIC_MT-	AI	Handset microphone signal input; phase-		Audio
17	ON_OFF	I	Input command for switching power ON or OFF (toggle command).	47K Ω	Pull Up to VBATT
18	AXE	I	Handsfree switching	100K Ω	CMOS 2.8V
19	SIMIO	I/O	External SIM signal - Data I/O		1.8 / 3V
20	C103/TXD	I	Serial data input (TXD) from DTE		CMOS 2.8V
21	PWRMON	O	Module Status ON indication (Signal output for power on/off control of external devices)	1K Ω	CMOS 2.8V
22	SIMVCC	-	External SIM signal – Power (3)		1.8 / 3V
23	RESET	I	Reset input		
24	SIMRST	O	External SIM signal – Reset		1.8 / 3V
25	RESERVED	-	RESERVED		-
26	SIMCLK	O	External SIM signal – Clock		1.8 / 3V
27	SIMIN	I/O	External SIM signal – Presence (active low)	47K Ω	CMOS 2.8V
28	GPO2 / JDR	O	General purpose output (Open Collector) / Jammer Detect Report		Open Collector
29	C106/CTS	O	Output for Clear to send signal (CTS) to DTE		CMOS 2.8V
30	C125/RING	O	Output for Ring indicator signal (RI) to DTE		CMOS 2.8V
31	GPI1	I	General purpose input		transistor base
32	GPIO8	I/O	Configurable general purpose I/O pin		CMOS 2.8V
33	C107/DSR	O	Output for Data set ready signal (DSR) to DTE		CMOS 2.8V
34	GPIO9	I/O	Configurable general purpose I/O pin		CMOS 2.8V
35	TX_GPS	O	TX Data NMEA GPS protocol		CMOS 2.8V
36	C109/DCD	O	Output for Data carrier detect signal (DCD) to DTE		CMOS 2.8V
37	C104/RXD	O	Serial data output to DTE		CMOS 2.8V
38	GPIO10/ CLK	I/O	Configurable general purpose I/O pin / Python DEBUG 4)		CMOS 2.8V
39	STAT_LED	O	Status indicator led		Open Collector
40	GPIO11	I/O	Configurable general purpose I/O pin	4.7 Kohm	CMOS 2.8V
41	RX_GPS	I	RX Data NMEA GPS protocol		CMOS 2.8V
42	GPIO12	I/O	Configurable general purpose I/O pin	47 Kohm	CMOS 2.8V



GM862 Family Hardware User Guide
1vv0300794 Rev. 0 – 03/12/2008

Pin	Signal	I/O	Function	Internal Pull up	Type
43	C108/DTR	I	Input for Data terminal ready signal (DTR) from DTE		CMOS 2.8V
44	GPIO13 / MRST	I/O	Configurable general purpose I/O pin / Python DEBUG (4)		CMOS 2.8V
45	C105/RTS	I	Input for Request to send signal (RTS) from DTE		CMOS 2.8V
46	GPIO3	I/O	Configurable general purpose I/O pin	47 Kohm	CMOS 2.8V
47	GPIO4	I/O	Configurable general purpose I/O pin / TX Disable Control	4.7 Kohm	CMOS 2.8V
48	GPIO5 / MTSR	I/O	Configurable general purpose I/O pin / Python DEBUG (4)		CMOS 2.8V
49	GPIO6 / ALARM	I/O	Configurable general purpose I/O pin / ALARM		CMOS 2.8V
50	GPIO7 / BUZZER	I/O	Configurable general purpose I/O pin / BUZZER		CMOS 2.8V

- (1) For the exclusive use of the Technical Support Service
- (2) An earphone with 150 ohm impedance can be directly connected to EAR+ and EAR-
- (3) On this pin a maximum of 10nF bypass capacitor is allowed.
- (4) This output requires an external circuit to connect it to a serial port.

On GM862-QUAD and GM862-QUAD-PY the signals are defined as in the following table:

35	TX_TRACE	0	TX Data for Python Debug (only on GM862-QUAD-PY)		CMOS 2.8V
38	GPIO10	I/O	Configurable general purpose I/O pin		CMOS 2.8V
41	RX_TRACE	1	RX Data for Python Debug (only on GM862-QUAD-PY)		CMOS 2.8V
44	GPIO13	I/O	Configurable general purpose I/O pin		CMOS 2.8V
48	GPIO5	I/O	Configurable general purpose I/O pin		CMOS 2.8V

If not used, almost all pins must be left disconnected. The only exceptions are the following pins:

pin	signal
1,3,5,7	VBATT
2,4,8	GND
17	ON/OFF*
20	TXD
23	RESET*
37	RXD
45	RTS (1)

- (1) RTS must be connected to the GND (on the module side) if flow control is not used

3.5. Antenna Connectors

The Telit GM862-GPS includes two 50 Ohm MMCX coaxial female RF connectors (only one in case of GM862-QUAD / QUAD-PY). On the user application side the following connector must be used:



The RESET is internally controlled on start-up to achieve always a proper power-on reset sequence, so there is no need to control this pin on start-up. It may only be used to reset a device already on that is not responding to any command.



NOTE:

Do not use this signal to power off the GM862. Use the ON/OFF signal (Pin 17 of SO301) to perform this function or the AT#SHDN command.

Reset signal operating levels

Signal	Min	Max
RESET Input high	2.0V (1)	2.2V
RESET Input low	0V	0.2V

(1) this signal is internally pulled up so the pin can be left floating if not used.

If unused, this signal may be left unconnected. If used, then it must always be connected with an open collector transistor, to permit to the internal circuitry the power on reset and under voltage lockout functions.



6.2. Turning OFF the GM862

The turning off of the device can be done in the following ways:

- by software command (see GM862 Software User Guide)
- by hardware shutdown
- by hardware unconditional shutdown (Unconditional Restart in case of GM862-QUAD / QUAD-PY)

When the device is shut down by software command or by hardware shutdown, it issues to the network a detach request that informs the network that the device will not be reachable any more. The hardware unconditional shutdown does not issue this request and shuts down immediately the device.

6.2.1. Hardware Shutdown

To turn OFF the GM862 the pin ON# must be tied low for at least 1 second and then released.

The same circuitry and timing for the power on shall be used.

The device shuts down after the release of the ON# pin.



TIP:

To check if the device has powered off, the hardware line PWRMON must be monitored. When PWRMON goes low, the device has powered off.


6.2.2. Hardware Unconditional Shutdown

To unconditionally Shutdown the GM862-GPS the pin RESET# must be tied low for at least 200 milliseconds and then released.

The maximum current that can be drained from the RESET# pin is 0,15 mA.



A simple circuit to do it is:



NOTE:

Do not use any pull up resistor on the RESET# line nor any totem pole digital output. Using pull up resistor may bring to latch up problems on the GM862 power regulator and improper functioning of the module. The line RESET# must be connected only in open collector configuration.




TIP:

The unconditional hardware reset must always be implemented on the boards and must be used by the software as an emergency exit procedure.

For example:

Let us assume you need to drive the RESET# pin with a totem pole output of a +3/5 V microcontroller (uP_OUT2):





The hardware unconditional shutdown must not be used during normal operation of the device since it does not detach the device from the network. It shall be kept as an emergency exit procedure to be done in the rare case that the device gets stacked waiting for some network or SIM responses.


If device does not respond to a command in the timeout window, retry issuing the command and if still no response is received a hardware reset shall be issued.

6.2.3. Hardware Unconditional Restart

To unconditionally Restart the GM862-QUAD/QUAD-PY the pin RESET# must be tied low for at least 200 milliseconds and then released.

The maximum current that can be drained from the RESET# pin is 0,15 mA.

A simple circuit to do it is:



GM862 Family Hardware User Guide
1vv0300794 Rev. 0 – 03/12/2008

In case of GM862-GPS with p/n 3990250689 the GPS consumptions are reduced by a 30%:

	GM862-GPS (3 990 250 657)	GM862-GPS (3 990 250 659)
Operating current	70 mA \pm 20%, including 50 mA for the GPS hardware and 20 mA for the antenna LNA	55mA, including 35mA GPS for the GPS hardware and 20 mA for the antenna LNA

GM862-QUAD / QUAD-PY CONSUMPTIONS		
Mode	Average (mA)	Mode description
IDLE mode		
		Stand by mode; no call in progress
AT+CFUN=1	23,9	Normal mode: full functionality of the module
AT+CFUN=4	22	Disabled TX and RX; module is not registered on the network
AT+CFUN=0 or AT+CFUN=5	7,20 / 3,56 (1)	Power saving: CFUN=0 module registered on the network and can receive voice call or an SMS; but it is not possible to send AT commands; module wakes up with an unsolicited code (call or SMS) or rising RTS line. CFUN=5 full functionality with power saving; module registered on the network can receive incoming calls and SMS
RX mode		
1 slot in downlink	52,3	GSM Receiving data mode
2 slot in downlink	65,2	
3 slot in downlink	78,6	
4 slot in downlink	88,4	
GSM TX and RX mode		
Min power level	78,1	GSM Sending data mode
Max power level	200,1	
GPRS (class 10) TX and RX mode		
Min power level	123,7	GPRS Sending data mode
Max power level	370,8	

(1) Worst/best case depends on network configuration and is not under module control.

The GSM system is made in a way that the RF transmission is not continuous, else it is packed into bursts at a base frequency of about 216 Hz, the relative current peaks can be as high as about 2A. Therefore the power supply has to be designed in order to withstand with these current peaks without big voltage drops; this means that both the electrical design and the board layout must be designed for this current flow.

If the layout of the PCB is not well designed a strong noise floor is generated on the ground and the supply; this will reflect on all the audio paths producing an audible annoying noise at 216 Hz; if the voltage drop during the peak current absorption is too much, then the device may even shutdown as a consequence of the supply voltage drop.



TIP:

The power supply must be designed so that it is capable of a peak current output of at least 2 A.



7.2. General Design Rules

The principal guidelines for the Power Supply Design embrace three different design steps:

- the electrical design
- the thermal design.
- the PCB layout.

7.2.1. Electrical Design Guidelines

The electrical design of the power supply depends strongly from the power source where this power is drained. We will distinguish them into three categories:

- +5V input (typically PC internal regulator output)
- +12V input (typically automotive)
- Battery

7.2.1.1. +5V input Source Power Supply Design Guidelines

The desired output for the power supply is 3.8V, hence there is not a big difference between the input source and the desired output and a linear regulator can be used. A switching power supply will not be suited because of the low drop out requirements.

When using a linear regulator, a proper heat sink shall be provided in order to dissipate the power generated.

A Bypass low ESR capacitor of adequate capacity must be provided in order to cut the current absorption peaks close to the GM862, a 100 μ F tantalum capacitor is usually suited.

Make sure the low ESR capacitor on the power supply output (usually a tantalum one) is rated at least 10V.

A protection diode must be inserted close to the power input, in order to save the GM862 from power polarity inversion.

An example of linear regulator with 5V input is:



battery pack capacity. During this phase the voltage across the battery terminals still raises but at a lower rate.

Once the battery voltage reaches its maximum voltage then the process goes into its third state: Final charging. The voltage measure to change the process status into final charge is very important. It must be ensured that the maximum battery voltage is never exceeded, otherwise the battery may be damaged and even explode. Moreover for the constant voltage final chargers, the constant voltage phase (final charge) must not start before the battery voltage has reached its maximum value, otherwise the battery capacity will be highly reduced.

The final charge can be of two different types: constant voltage or pulsed. GM862 uses constant voltage.

The constant voltage charge proceeds with a fixed voltage regulator (very accurately set to the maximum battery voltage) and hence the current will decrease while the battery is becoming charged. When the charging current falls below a certain fraction of the fast charge current value, then the battery is considered fully charged, the final charge stops and eventually starts the maintenance.

The pulsed charge process has no voltage regulation, instead the charge continues with pulses. Usually the pulse charge works in the following manner: the charge is stopped for some time, let us say few hundreds of ms, then the battery voltage will be measured and when it drops below its maximum value a fixed time length charging pulse is issued. As the battery approaches its full charge the off time will become longer, hence the duty-cycle of the pulses will decrease. The battery is considered fully charged when the pulse duty-cycle is less than a threshold value, typically 10%, the pulse charge stops and eventually the maintenance starts.

The last phase is not properly a charging phase, since the battery at this point is fully charged and the process may stop after the final charge. The maintenance charge provides an additional charging process to compensate for the charge leak typical of a Li-Ion battery. It is done by issuing pulses with a fixed time length, again few hundreds of ms, and a duty-cycle around 5% or less.

This last phase is not implemented in the GM862 internal charging algorithm, so that the battery once charged is left discharging down to a certain threshold so that it is cycled from full charge to slight discharge even if the battery charger is always inserted. This guarantees that anyway the remaining charge in the battery is a good percentage and that the battery is not damaged by keeping it always fully charged (Li-Ion rechargeable battery usually deteriorate when kept fully charged).

Last but not least, in some applications it is highly desired that the charging process restarts when the battery is discharged and its voltage drops below a certain threshold, GM862 internal charger does it.

As you can see, the charging process is not a trivial task to be done; moreover all these operations must start only if battery temperature is inside a charging range, usually 5°C - 45°C.

The GM862 measures the temperature of its internal component, in order to satisfy this last requirement, it is not exactly the same as the battery temperature but in





NOTE:

The average consumption during transmissions depends on the power level at which the device is requested to transmit by the network. The average current consumption hence varies significantly.



TIP:

The thermal design for the Power supply must be made keeping an average consumption at the max transmitting level during calls of 500mA rms.

Considering the very low current during idle, especially if Power Saving function is enabled, it is possible to consider from the thermal point of view that the device absorbs current significantly only during calls.

If we assume that the device stays into transmission for short periods of time (let us say few minutes) and then remains for a quite long time in idle (let us say one hour), then the power supply has always the time to cool down between the calls and the heat sink could be smaller than the calculated one for 500mA maximum RMS current, or even could be the simple chip package (no heat sink).

Moreover in the average network conditions the device is requested to transmit at a lower power level than the maximum and hence the current consumption will be less than the 500mA, being usually around 200mA.

For these reasons the thermal design is rarely a concern and the simple ground plane where the power supply chip is placed can be enough to ensure a good thermal condition and avoid overheating.

7.2.3. Power Supply PCB Layout Guidelines

As seen on the electrical design guidelines the power supply shall have a low ESR capacitor on the output to cut the current peaks and a protection diode on the input to protect the supply from spikes and polarity inversion. The placement of these components is crucial for the correct working of the circuitry. A misplaced component can be useless or can even decrease the power supply performances.

The Bypass low ESR capacitor must be placed close to the Telit GM862 power input pins or in the case the power supply is a switching type it can be placed close to the inductor to cut the ripple provided the PCB trace from the capacitor to the GM862 is wide enough to ensure a dropleless connection even during the 2A current peaks.

The protection diode must be placed close to the input connector where the power source is drained.

The PCB traces from the input connector to the power regulator IC must be wide enough to ensure no voltage drops occur when the 2A current peaks are absorbed. Note that this is not made in order to save power loss but especially to avoid the



voltage drops on the power line at the current peaks frequency of 216 Hz that will reflect on all the components connected to that supply, introducing the noise floor at the burst base frequency. For this reason while a voltage drop of 300-400 mV may be acceptable from the power loss point of view, the same voltage drop may not be acceptable from the noise point of view. If your application does not have audio interface but only uses the data feature of the Telit GM862, then this noise is not so disturbing and power supply layout design can be more forgiving.

The PCB traces to the GM862 and the Bypass capacitor must be wide enough to ensure no voltage drops occur when the 2A current peaks are absorbed. This is for the same reason as previous point. Try to keep this trace as short as possible.

The PCB traces connecting the Switching output to the inductor and the switching diode must be kept as short as possible by placing the inductor and the diode very close to the power switching IC (only for switching power supply). This is done in order to reduce the radiated field (noise) at the switching frequency (100-500 kHz usually).

The use of a good common ground plane is suggested.

The placement of the power supply on the board must be done in such a way to guarantee that the high current return paths in the ground plane are not overlapped to any noise sensitive circuitry as the microphone amplifier/buffer or earphone amplifier.

The power supply input cables must be kept separate from noise sensitive lines such as microphone/earphone cables.

7.2.4. Parameters for ATEX Application

In order to integrate the Telit's GE862 module into an ATEX application, the appropriate reference standard IEC EN xx and integrations shall be followed.

Below are listed parameters and useful information to integrate the module in your application:

- GM862-QUAD & GM862-PY
 - Total capacity: 78.596 μ F
 - Total inductance: 10.383 μ H
- GM862-GPS
 - Total capacity: 83.167 μ F
 - Total inductance: 10.485 μ H
- No voltage upper than supply voltage is present in the module.
- No step-up converters are present in the module.
- In abnormal conditions, the maximum RF output power is 34 dBm for few seconds.



GM862 Family Hardware User Guide
1vv0300794 Rev. 0 – 03/12/2008

For this particular application, we recommend the customer to involve TTSC (Telit Technical Support Center) in the design phase of the application.



8. Serial Ports

8.1. GM862-GPS SERIAL PORTS

The serial port on the Telit GM862-GPS is the core of the interface between the module and OEM hardware.

2 serial ports are available on the module:

- MODEM SERIAL PORT
- GPS SERIAL PORT (NMEA)

8.2. GM862-QUAD/ QUAD-PY SERIAL PORTS

The serial port on the Telit GM862-QUAD/ QUAD-PY is the core of the interface between the module and OEM hardware.

2 serial ports are available on the module:

- MODEM SERIAL PORT
- TRACE (Usable only on GM862-QUAD-PY for Python Debug)

8.3. MODEM SERIAL PORT

Several configurations can be designed for the serial port on the OEM hardware, but the most common are:

- RS232 PC com port
- microcontroller UART @ 2.8V - 3V (Universal Asynchronous Receive Transmit)
- microcontroller UART@ 5V or other voltages different from 2.8V

Depending from the type of serial port on the OEM hardware a level translator circuit may be needed to make the system work. The only configuration that does not need a level translation is the 2.8V UART.

The MODEM serial port on the GM862 is a +2.8V UART with all the 7 RS232 signals. It differs from the PC-RS232 in the signal polarity (RS232 is reversed) and levels. The levels for the GM862 UART are the CMOS levels:

Absolute Maximum Ratings - Not Functional

Parameter	Min	Max
Input level on any digital pin when on	-0.3V	+3.6V
Input voltage on analog pins when on	-0.3V	+3.0 V



In order to translate the whole set of control lines of the UART you will need:

- 5 driver
- 3 receiver




NOTE:

The digital input lines working at 2.8VCMOS have an absolute maximum input voltage of 3,6V; therefore the level translator IC shall not be powered by the +3.8V supply of the module. Instead it shall be powered from a +2.8V / +3.0V (dedicated) power supply.

This is because in this way the level translator IC outputs on the module side (i.e. GM862 inputs) will work at +3.8V interface levels, stressing the module inputs at its maximum input voltage.

An example of level translation circuitry of this kind is:



RS232 LEVEL TRSANSULATOR

The RS232 serial port lines are usually connected to a DB9 connector with the following layout:





TIP:

This logic IC for the level translator and 2.8V pull-ups (not the 5V one) can be powered directly from PWRMON line of the GM862. Note that the TC7SZ07AE has open drain output, therefore the resistor R2 is mandatory.



NOTE:

The UART input line TXD (rx_uart) of the GM862S is NOT internally pulled up with a resistor, so there may be the need to place an external 47K Ω pull-up resistor, either the DTR (dtr_uart) and RTS (rts_uart) input lines are not pulled up internally, so an external pull-up resistor of 47K Ω may be required.

A power source of the internal interface voltage corresponding to the 2.8VCMOS high level is available at the PWRMON pin on the connector, whose absolute maximum output current is 1mA.

A maximum of 9 resistors of 47 K Ω pull-up can be connected to the PWRMON pin, provided no other devices are connected to it and the pulled-up lines are GM862 input lines connected to open collector outputs in order to avoid latch-up problems on the GM862.

Care must be taken to avoid latch-up on the GM862 and the use of this output line to power electronic devices shall be avoided, especially for devices that generate spikes and noise such as switching level translators, micro controllers, failure in any of these condition can severely compromise the GM862 functionality.



NOTE:

The input lines working at 2.8VCMOS can be pulled-up with 47K Ω resistors that can be connected directly to the PWRMON line provided they are connected as in this example.

NO OTHER devices than those suggested must be powered with the PWRMON line; otherwise the module functionality may be compromised.

It is important to consider that the added circuit must have consumption lower than 1mA.

In case of reprogramming of the module has to be considered the use of the RESET line to start correctly the activity.

The preferable configuration is having an external supply for the buffer.



You must keep in mind the different audio characteristics of the transmit blocks when designing:

The “**MIC_MT**” audio path must be used for handset function, while the “**MIC_HF**” audio path is suited for hands-free function (car kit).



TIP:

Being the microphone circuitry the more noise sensitive, its design and layout must be done with particular care. Both microphone paths are balanced and the OEM circuitry must be balanced designed to reduce the common mode noise typically generated on the ground plane. However also an unbalanced circuitry can be used for particular OEM application needs.

TIP:

Due to the difference in the echo canceller type, the “**Mic_MT**” audio path is suited for Handset applications, while the “**Mic_HF**” audio path is suited for hands-free function (car kit). The Earphone applications must be made using the “**Mic_HF**” audio path but **DISABLING** the echo canceller by software AT command. If the echo canceller is left active with the Earphone, then some echo might be introduced by the echo cancel algorithm.

9.1.2. Input Lines Characteristics

“MIC_MT” 1st differential microphone path	
Line Coupling	AC*
Line Type	Balanced
Coupling capacitor	≥ 100nF
Differential input resistance	50kΩ
Differential input voltage	≤ 1,03V _{pp} (365mV _{rms})
Microphone nominal sensitivity	-45 dBV _{rms} /Pa
Analog gain suggested	+ 20dB
Echo canceller type	Handset



"MIC_HF" 2nd differential microphone path	
Line Coupling	AC*
Line Type	Balanced
Coupling capacitor	$\geq 100\text{nF}$
Differential input resistance	50k Ω
Differential input voltage	$\leq 65\text{mV}_{\text{pp}}$ (23mV _{rms})
Microphone nominal sensitivity	-45 dBV _{rms} /Pa
Analog gain suggested	+10dB
Echo canceller type	Car kit hands-free



***WARNING:** AC means that the signals from microphone have to be connected to input lines of the module by a CAPACITOR, which value must be $\geq 100\text{nF}$. Not respecting this constraint, the input stage will be damaged.

9.2. OUTPUT LINES (Speaker)

9.2.1. Short Description

The Telit GM862 provides two audio paths in receive section. Only one of the two paths can be active at a time, selectable by AXE hardware line or by AT command.

You must keep in mind the different audio characteristics of the receive blocks when designing:

- the "EAR_MT" lines EPN1 and EPP1 are the Differential Line-Out Drivers ; they can drive an external amplifier or directly a 16 Ω earpiece at -12dBFS (*);
- the "EAR_HF" lines EPPA1_2 and EPPA2 are the Fully Differential Power Buffers ; they can directly drive a 16 Ω speaker in differential (balanced) or single ended (unbalanced) operation mode .

(*) FS: Full Scale. It is equal to 0dB, the maximum Hardware Analog Receive Gain of BaseBand Chip.

The "EAR_MT" audio path must be used for handset function, while the "EAR_HF" audio path is suited for hands-free function (car kit).


Both receiver outputs are B.T.L. type (Bridged Tie Load) and the OEM circuitry shall be designed bridged to reduce the common mode noise typically generated on the ground plane and to get the maximum power output from the device; however also a single ended circuitry can be designed for particular OEM application needs.



- GPIO6 supports all three modes and can be input, output, ALARM output (Alternate function)
- GPIO7 supports all three modes and can be input, output, BUZZER output (Alternate function)

All GPIO pins except from GPIO1 and GPIO2 that are buffered with a transistor, are 2.8V CMOS signals.

ch1: ON_OFF (2sec)
ch2: GPIO 06 [bis]



10.1. GPIO Logic Levels

Where not specifically stated, all the interface circuits work at 2.8V CMOS logic levels.

The following table shows the logic level specifications used in the GM862 interface circuits:

Absolute Maximum Ratings -Not Functional

Parameter	Min	Max
Input level on any digital pin when on	-0.3V	+3.6V
Input voltage on analog pins when on	-0.3V	+3.0 V

Operating Range - Interface levels (2.8V CMOS)

Level	Min	Max
Input high level	2.1V	3.3V
Input low level	0V	0.5V
Output high level	2.2V	3.0V
Output low level	0V	0.35V



Operating Range - Interface levels (1.8V CMOS)

Level	Min	Max
Input high level	1.6V	2.2V
Input low level	0V	0.4V
Output high level	1,65V	2.2V
Output low level	0V	0.35V

10.2. Using a GPIO Pin as INPUT

The GPIO pins, when used as inputs, can be connected to a digital output of another device and report its status, provided this device has interface levels compatible with the 2.8V CMOS levels of the GPIO.

If the digital output of the device to be connected with the GPIO input pin has interface levels different from the 2.8V CMOS, then it can be connected to GPIO1 or can be buffered with an open collector transistor, provided with a 47KΩ pull-up resistor to 2.8V.

10.3. Using a GPIO Pin as OUTPUT

The GPIO pins, when used as outputs, can drive 2.8V CMOS digital devices or compatible hardware. When set as outputs, the pins (except from GPIO2 which is Open Collector) have a push-pull output and therefore the pull-up resistor may be omitted.

The GPIO2 pin, since it is an Open Collector output needs an external pull-up resistor.

10.4. Using the RF Transmission Control GPIO4

The GPIO4 pin, when configured as RF Transmission Control Input, permits to disable the Transmitter when the GPIO is set to Low by the application.

10.5. Using the RFTXMON Output GPIO5

The GPIO5 pin, when configured as RFTXMON Output, is controlled by the GM862-GPS module and will rise when the transmitter is active and fall after the transmitter activity is completed.

For example, if a call is started, the line will be HIGH during all the conversation and it will be again LOW after hanged up.

The line rises up 300ms before first TX burst and will became again LOW from 500ms to 1sec after last TX burst.



10.6. Using the Alarm Output GPIO6

The GPIO6 pin, when configured as Alarm Output, is controlled by the GM862 module and will rise when the alarm starts and fall after the issue of a dedicated AT command.

This output can be used to power up the GM862 controlling microcontroller or application at the alarm time, giving you the possibility to program a timely system wake-up to achieve some periodic actions and completely turn off either the application and the GM862 during sleep periods, dramatically reducing the sleep consumption to few μA .

In battery powered devices this feature will greatly improve the autonomy of the device.



NOTE:


During RESET the line is set to HIGH logic level.

10.7. Using the Buzzer Output GPIO7

The GPIO7 pin, when configured as Buzzer Output, is controlled by the GM862 module and will drive with appropriate square waves a Buzzer driver.

This permits to your application to easily implement Buzzer feature with ringing tones or melody played at the call incoming, tone playing on SMS incoming or simply playing a tone or melody when needed by your application.

A sample interface scheme is included below to give you an idea of how to interface a Buzzer to the GPIO7:





NOTE:

To correctly drive a buzzer a driver must be provided, its characteristics depend on the Buzzer and for them refer to your buzzer vendor.



11. ADC Section

11.1. ADC Converter

11.1.1. Description

The GM862 module provides one Analog to Digital Converter. The input line (named ADC_IN1) is available on Pin #6 of the Module's connector of the module and on pin 19 of PL103 on EVK2 Board.

The on board A/D is 11-bit converter. It is able to read a voltage level in the range of 0÷2 volts applied on the ADC pin input, store and convert it into 11 bit word.

	Min	Max	Units
Input Voltage range	0	2	Volt
AD conversion	-	11	bits
Resolution	-	< 1	mV

11.1.2. Using ADC Converter

The AT command below is available to use the ADC function:

AT#ADC=1,2

The read value is expressed in mV

Refer to SW user guide or to GM862 AT commands specification for the full description of this function.



12. Indication of Network Service Availability

The STAT_LED pin status shows information on the network service availability and Call status. The pin is an Open Collector output where it is possible to directly connect a LED to show information on the network service availability and Call status.

Therefore, the status indicated in the following table is reversed with respect to the pin status.

LED status	Device Status
permanently off	device off
fast blinking (period 1s, Ton 0,5s)	Net search / Not registered / turning off
slow blinking (period 3s, Ton 0,3s)	Registered full service
permanently on	a call is active







13. Mounting the GM862 Module on the Board

In order to electrically connect your board to the Telit GM862 modules, use a CSTP 2x25 pin vertical SMD SCH–SCH Molex 53748 - 0504 (female, low profile) as a counterpart to the CSTP 50 pin vertical SMD Molex 52991–0508 (male) of your Telit GM86.

When mounting the Telit GM862 on your board, take care of soldering the GM862 shielding reeds on a ground plane or signal.

Molex 53748-0504 (female, low profile) Connector LAY-OUT



NOTE:

Be very careful when connecting the Telit GM862 module RF connector. The Telit GM862 module RF connector can be damaged if not connected with the proper antenna RF connector. The minimum number of insertion cycles is recommended.


13.1. Antenna Coaxial Cable Fixing

The following constraints must be respected in the Telit GM862 modules antenna cable connection:



- The fixing point of the coaxial cable must not be placed too close to the antenna connector of the GM862 module, leaving at least 30mm of flexible cable between the fixed point and the plug end.
- The fixing point must be at the same height of the GM862 module antenna connector, eventually using a wedge between the PCB and the cable if it is directly fixed to the PCB.
- The flexible cable must never be bent with a radius lower than 25mm (RG174 cable).
- The cable must be a RG174 type or more flexible ones.

The following pictures explain these constraints:



NOTE:

in the examples the cable is always bent, this is not a constrain. If the installation does not require it, then the cable can be kept straight, ensuring that the fixing is without sliding.

13.2. Precautions

The plug must be inserted in the connector only after the installation of the Telit GM862 modules in the board. This is to prevent accidental breaking of the antenna connection during the transport.

The coaxial cable must be fixed at least in one point, without sliding possibilities.

The plug insertion/removal must be done axially with the female connector of the GM862, keeping lateral strains to a minimum.

The insertion/crimping pull out force must be less than 15N.

The Hole's diameter for GM862 shielding reed soldering is: (1.5 +/- 0.05) mm.



16. Document Change Log

Revision	Date	Changes
ISSUE#0	03/12/08	Release First ISSUE# 0

